



AW400BT with GSM

User Manual

Version 1.1

Last Revised February 5, 2013

**All contents in this manual are copyrighted by ArWest Communications.
All rights reserved. The information contained herein may not be used, accessed, copied,
stored, displayed, sold, modified, published, or distributed, or otherwise reproduced without
express written consent from ArWest Communications.**

TABLE OF CONTENTS

Preface	7
Terms and Conditions	7
Regulatory Information	9
Manual Conventions	10
Screen Captures	10
Technical Assistance	10
Chapter 1. Introduction	11
1.1. Getting Acquainted	12
1.1.1. LEDs	12
1.1.2. Data and Power Port	12
1.1.3. External Antenna and GSM Antenna Connectors	13
1.1.4. Mounting Bracket	13
1.1.5. Cables	13
1.1.6. Literature	14
1.1.7. External GSM Antenna	14
1.1.8. External RF Antenna (not included)	14
1.1.9. Storage Precautions	14
Chapter 2. Configuration	15
2.1. Powering AW400BT with GSM	15
2.1.1. Power supply requirements	15
2.2. RF Antenna Installation	16
2.3. GSM Antenna Installation	18
2.4. Installing AWLaunch	18
2.5. Connecting AW400BT with GSM and Computer	18
2.5.1. Connecting through serial port	18
2.5.2. Connecting through USB port	19
2.5.3. Connecting through Bluetooth®	19
2.6. Configuring AW400BT with GSM	19
2.6.1. Sleep Mode and Alarm settings	27
2.7. Checking Firmware Version	28
2.8. Loading New Firmware	29

Chapter 3. Internet services.	31
3.1. TCP client	31
3.2. TCP server	32
3.2.1. RTN corrections uploading	32
3.2.2. Remote CLI support	33
3.3. NTRIP client	34
Chapter 4. Command Line Interface	37
4.1. Command Line Interface Convention.	37
4.1.1. Software Switching to Maintenance Mode	38
4.1.2. Hardware Switching to Maintenance Mode	39
4.1.3. Switching to Data Mode	39
4.2. Networking Commands	39
4.2.1. LINK	39
4.3. Serial Interfacing Commands	41
4.3.1. DPORT	41
4.3.2. MPORT	42
4.4. Special Commands	42
4.4.1. BOOT	42
4.4.2. HELP	42
4.4.3. SAVE	43
4.4.4. SLEEP	43
4.5. Diagnostics and Identification Commands	44
4.5.1. INFO	44
4.5.2. STATE	44
4.6. RTN	45
4.7. GSM	47
Appendix A. Specifications	49
A.1. AW400BT with GSM Modem Specifications	49
A.1.1. General Radio Specifications	49
A.1.2. Environmental Specifications	50
A.1.3. Transmitter Specifications	50
A.1.4. Receiver Specifications	51
A.2. Internet Services	52
A.3. Compliance	52
A.4. Connector Specifications	52

Appendix B. UHF Radio Usage55

Appendix C. Safety Warnings57

 C.1. General Warnings58

Appendix D. Warranty Terms59

PREFACE

Thank you for purchasing this product. The materials available in this Manual (the “Manual”) have been prepared by ArWest Communications, Corp. (“ArWest”) for owners of ArWest products. It is designed to assist owners with the use of AW400BT with GSM modem and its use is subject to these terms and conditions (the “Terms and Conditions”).

Note: Please read these Terms and Conditions carefully.

Terms and Conditions

USE – ArWest modems are designed to be used by a professional. The user is expected to have a good knowledge and understanding of the user and safety instructions before operating, inspecting or adjusting.

COPYRIGHT – All information contained in this Manual is the intellectual property of, and copyrighted material of ArWest. All rights are reserved. You may not use, access, copy, store, display, create derivative works of, sell, modify, publish, distribute, or allow any third party access to, any graphics, content, information or data in this Manual without ArWest’ express written consent and may only use such information for the care and operation of your AW400BT with GSM. The information and data in this Manual are a valuable asset of ArWest and are developed by the expenditure of considerable work, time and money, and are the result of original selection, coordination and arrangement by ArWest.

TRADEMARKS – AW400BT with GSM™, AWLaunch™, ArWest® are trademarks or registered trademarks of ArWest Communications Corp. Windows® is a registered trademark of Microsoft Corporation; Bluetooth® word mark is owned by the Bluetooth SIG, Inc. Product and company names mentioned herein may be trademarks of their respective owners.

DISCLAIMER OF WARRANTY – EXCEPT FOR ANY WARRANTIES IN THIS MANUAL OR A WARRANTY CARD ACCOMPANYING THE PRODUCT, THIS MANUAL AND THE AW400BT WITH GSM MODEM ARE PROVIDED “AS-IS.” THERE ARE NO OTHER WARRANTIES. ARWEST DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE. ARWEST AND ITS DISTRIBUTORS SHALL NOT BE LIABLE FOR TECHNICAL OR EDITORIAL ERRORS OR OMISSIONS CONTAINED HEREIN; NOR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE FURNISHING, PERFORMANCE OR USE OF THIS MATERIAL OR THE AW400BT with GSM MODEM. SUCH DISCLAIMED DAMAGES INCLUDE BUT ARE NOT LIMITED TO LOSS OF TIME, LOSS OR DESTRUCTION OF DATA, LOSS OF PROFIT, SAVINGS OR REVENUE, OR LOSS OF THE PRODUCT'S USE. IN ADDITION, ARWEST IS NOT RESPONSIBLE OR LIABLE FOR DAMAGES OR COSTS INCURRED IN CONNECTION WITH OBTAINING SUBSTITUTE PRODUCTS OR SOFTWARE, CLAIMS BY OTHERS, INCONVENIENCE, OR ANY OTHER

Preface

Terms and Conditions

COSTS. IN ANY EVENT, ARWEST SHALL HAVE NO LIABILITY FOR DAMAGES OR OTHERWISE TO YOU OR ANY OTHER PERSON OR ENTITY IN EXCESS OF THE PURCHASE PRICE FOR AW400BT WITH GSM.

LICENSE AGREEMENT – Use of any computer programs or software supplied by ArWest or downloaded from a ArWest website (the “Software”) in connection with AW400BT with GSM constitutes acceptance of these Terms and Conditions in this Manual and an agreement to abide by these Terms and Conditions. The user is granted a personal, non-exclusive, non-transferable license to use such Software under the terms stated herein and in any case only with a single AW400BT with GSM or single computer. You may not assign or transfer the Software or this license without the express written consent of ArWest. This license is effective until terminated. You may terminate the license at any time by destroying the Software and Manual. ArWest may terminate the license if you fail to comply with any of the Terms or Conditions. You agree to destroy the Software and manual upon termination of your use of AW400BT with GSM. All ownership, copyright and other intellectual property rights in and to the Software belong to ArWest. If these license terms are not acceptable, return any unused software and manual.

CONFIDENTIALITY – This Manual, its contents and the Software (collectively, the “Confidential Information”) are the confidential and proprietary information of ArWest. You agree to treat ArWest' Confidential Information with a degree of care no less stringent that the degree of care you would use in safeguarding your own most valuable trade secrets. Nothing in this paragraph shall restrict you from disclosing Confidential Information to your employees as may be necessary or appropriate to operate or care for AW400BT with GSM. Such employees must also keep the Confidentiality Information confidential. In the event you become legally compelled to disclose any of the Confidential Information, you shall give ArWest immediate notice so that it may seek a protective order or other appropriate remedy.

WEBSITE; OTHER STATEMENTS – No statement contained at the ArWest website (or any other website) or in any other advertisements or ArWest literature or made by an employee or independent contractor of ArWest modifies these Terms and Conditions (including the Software license, warranty and limitation of liability).

SAFETY – Improper use of AW400BT with GSM can lead to injury to persons or property and/or malfunction of the product. The AW400BT with GSM modem should only be repaired by authorized ArWest warranty service centers. Users should review and heed the safety warnings in Appendix C.

MISCELLANEOUS – The above Terms and Conditions may be amended, modified, superseded, or canceled, at any time by ArWest. The above Terms and Conditions will be governed by, and construed in accordance with, the laws of the State of California, without reference to conflict of laws.

Regulatory Information

FCC Class A Compliance

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

CAUTION: *Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void your authority to operate such equipment.*

Canadian Emissions Labeling Requirements

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Industry Canada

The term “IC:” before the equipment certification number only signifies that the Industry Canada technical specifications were met.

WEEE Directive

The following information is for EU-member states only: The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the take-back and recycling of this product, please contact your supplier where you purchased the product or consult.



Preface

Manual Conventions

WEEE Directive

Manual Conventions

This manual uses the following conventions:

Example	Description
<i>File ▶ Exit</i>	Click the <i>File</i> menu and click <i>Exit</i>
<i>Link Space</i>	This format represents titles of dialog windows/boxes, names of menu options, identifies program interface objects, such as checkboxes, edit boxes, radio buttons, etc.
Temp	This format is used to enter various string information (e.g., file and directory names) as well as operator commands.

Screen Captures

This manual includes sample screen captures. Your actual screen can look slightly different from the sample screen due to the modem you have connected, operating system used and settings you have specified. This is normal and not a cause for concern.

Technical Assistance

If you have a problem and cannot find the information you need in the product documentation, contact your local dealer. Alternatively, request technical support using the support@arwestcom.com.

INTRODUCTION

AW400BT with GSM is the up-to-date unsurpassed 4 W UHF radio transceiver with USB and Bluetooth® capacity, and built-in quad band GSM/GPRS module. AW400BT accesses Real Time Network (RTN) via GPRS, takes incoming data from the network, modulates it with GMSK, FSK, PSK or most spectrum efficient QAM modulation and transmits it at RF power output levels from 15 dBm up to 36 dBm operating in UHF frequency band (406 to 470 MHz). The data taken from RTN can be routed to the UART, USB or Bluetooth communication ports as well. AW400BT is also capable of receiving RF signal from remote UHF transmitter or data from communication ports (UART, USB or Bluetooth) and sending it over the cellular network using built-in GSM/GPRS module if such operation mode is selected.



Figure 1-1. AW400BT with GSM

The AW400BT with GSM radio transceiver provides a high-speed point-to-point and point-to-multipoint wireless data transfer at up to 38.4 kbps. The firmware supports user selectable modulation techniques, which allows the user achieving the highest data speed for a given range. It also includes a selectable error correction, which improves the functioning of the radio modem under interference. The sophisticated features of AW400BT with GSM include data scrambling, frequency hopping, user selectable transmit output power level, low power consumption sleep modes, autoscanning for base and plug-and-play installation for remote terminals.

The firmware of the AW400BT with GSM radio modem resides in a flash memory. The updating of the radio modem programs is entirely software-based. The flash memory is re-programmable through an RS-232 interface, USB, Bluetooth. By accessing to the internet via GPRS the AW400BT with GSM provides remote CLI access and can be configured remotely (through the internet) if corresponding operation mode is selected.

Introduction

Getting Acquainted

LEDs

1.1. Getting Acquainted

The AW400BT with GSM is a rugged and very powerful external radio transceiver 146 mm wide 75 mm deep 44 mm high, weighs 488 g.

1.1.1. LEDs

External LED's (see Figure 1-2) are used for Link and Line status indication:

Position	LED Name	Description
1	PWR	Solid Green if external power connected.
2	UHF	Blinking if radio receives or transmits data over UHF.
3	GSM	Blinking if radio receives or transmits data over GSM.
4	BT	Blinking if radio receives or transmits Data over Bluetooth.

1.1.2. Data and Power Port

The AW400BT with GSM data and power port is placed on the front of the unit (Figure 1-2).



Figure 1-2. AW400BT with GSM front side

Through the DB15 port the AW400BT with GSM can be connected to PC with Accessory Data-Ser-Pwr Cable, DB9/DB15/SAE (6ft/1.8m) p/n 14-578108-02, or with ArWest receiver with Accessory Data-Ser-Pwr Cable, ODU-7/DB15/SAE (6ft/1,8m) p/n 14-578110-02 and can be powered. See “Powering AW400BT with GSM” on page 13 for detailed information.

1.1.3. External Antenna and GSM Antenna Connectors

The external antenna connects to the BNC external antenna connector and GSM antenna connects to the SMA connector which are placed on the back panel of AW400BT with GSM.




Figure 1-3. RF and GSM Antenna Connectors

1.1.4. Mounting Bracket

The mounting bracket (optional) connects the modem to a standard pole/adaptor (Figure 1-4).




Figure 1-4. Optional mounting bracket (p/n 10-587302-21)

1.1.5. Cables

The AW400BT with GSM package includes standard communication and power cable DB9/DB15/SAE (p/n 14-578110-02) for configuring the modem and providing a power source to the modem.



Figure 1-5. Cable DB9/DB15/SAE (p/n 14-578110-02)

Introduction

Getting Acquainted
Literature

1.1.6. Literature

AW400BT with GSM literature, including manuals and other product information are available on the ArWest website (<http://www.arwestcom.com>):

- *AW400BT with GSM Operator's Manual*
- Functional specifications

1.1.7. External GSM Antenna

GSM/GPRS Antenna 850/900/1800/1900MHZ, SMA (p/n 30-587314-01):



Figure 1-6. GSM Antenna

1.1.8. External RF Antenna (not included)

Antenna type depends on the site requirements, and may be directional or omni-directional.

Warning: *Do not use AW400BT with GSM without antenna to avoid serious damage of your device.*

1.1.9. Storage Precautions

1. Always clean the instrument after use. Wipe off dust with a cleaning brush, then wipe off dirt with a soft cloth.
2. Store in a location with a temperature of -40°C ... $+85^{\circ}\text{C}$, and no exposure to direct sunlight.
3. Use a clean cloth, moistened with a neutral detergent or water, to clean the modem. Never use an abrasive cleaner, ether, thinner benzene, or other solvents.

Always make sure the instrument is completely dry before storing. Dry the modem with a soft, clean cloth.

CONFIGURATION

2.1. Powering AW400BT with GSM

To power AW400BT with GSM use the Battery kit 1 (p/n 99-587300-10).



Figure 2-1. Battery Kit 1

2.1.1. Power supply requirements

A single external power supply is necessary to operate AW400BT with GSM. The external power supply needs to be Listed for US and Certified for EU countries, it needs also to be a Limited Power Source and rated for Outdoor Use and have an output rated for +9... +36V, 4A. This may not be the same range as other ArWest products with which you are familiar.

CAUTION: *To avoid the introduction of hazards when operating and installing, before connecting of the equipment to the supply, make sure that the supply meets local and national safety ordinances and matches the equipment's voltage and current requirements.*

CAUTION: *Never attempt any maintenance or cleaning of the supply while plugged in. Always remove supply from AC power before attempting service or cleaning.*

Warning: *If the voltage supplied is below the minimum specification, the modem will suspend operation. If the voltage supplied is above the maximum specification, the modem may be permanently damaged, voiding your warranty.*

Make sure cords are located so that will not be stepped on, tripped over, or otherwise subjected to damage or stress. Do not operate equipment with a damaged cord or plug – replace immediately.

Configuration

RF Antenna Installation

Power supply requirements

To reduce the risk of damage to the equipment, pull by the plug body rather than the output cord when disconnecting the equipment.

Do not operate the supply if it has received a sharp blow, been dropped, or otherwise damaged. Do not disassemble the supply.

Warning: *Before connecting the external power source and the modem, make sure that the power source matches the modem's voltage and current requirements.*

2.2. RF Antenna Installation

Warning: *To avoid the equipment serious damage, do not switch the modem to transmit mode if RF antenna is not connected!*

Select the type of antenna that best fits your application and the one that offers the highest dB gain. In addition, setup your system in the highest possible location to minimize obstacles between the transmitting and receiving systems. Always place the antenna on the highest point available. At a minimum, set the antenna to at least ten feet above the terrain using an antenna mast.

Some antennas intended to be attached to the pole mount adaptor (p/n 14-578117-01) are designed to be operated with a ground plane and some without it. Antennas operating without ground plane marked in our catalogue as NGP, e.g. UHF NGP Antenna 1/2, 2.4 dB gain, NMO:

- p/n 30-587307-01 UHF NGP Antenna 406-430 MHz, 1/2, 2.4 dB, NMO
- p/n 30-587308-01 UHF NGP Antenna 430-450 MHz, 1/2, 2.4 dB, NMO
- p/n 30-587309-01 UHF NGP Antenna 450-470 MHz, 1/2, 2.4 dB, NMO

These antennas are NO GROUND PLANE antennas with gain 2.4 dB and NMO specified connector type with should match with your antenna adapter (pole mount or magnet mount). Antennas designed to be operated with ground plane

- p/n 30-587303-01 UHF Antenna 406-430 MHz, 5/8, 5 dB, NMO
- p/n 30-587304-01 UHF Antenna 430-450 MHz, 5/8, 5 dB, NMO
- p/n 30-587305-01 UHF Antenna 450-470 MHz, 5/8, 5 dB, NMO

provide better gain, but to achieve the best performance of your antenna, add a UHF Antenna Ground Plane Disk (p/n 10-587400-01) to the bottom of the antenna for a ground plane. UHF antenna Ground Plane disk improves VSWR and as result increase RF power delivered from transmitter to antenna and system distance range.


To install antenna with ground plane disc (see pictures below):

1. Unscrew the cone-shaped cable part;
2. Place the ground plane disc between cable parts and screw all parts together;
3. Attach cable with ground plane to the UHF antenna;

4. Place the antenna on the pole.



1 Unscrew the cone-shaped cable part




2 Place the Ground Plane between cable parts and screw all together



+



3 Attach to the UHF Antenna



Use coaxial cable and connectors that are impedance-matched with the radio equipment, and make sure to use the shortest length of cable to move the signal between the radio and the antenna:

- p/n 14-578115-01 Accessory UHF Ant Cable TNC/Magn Mount, 12ft¹
- p/n 14-578116-01 Accessory UHF Ant Cable TNC/Mini-Magn Mount, 12ft¹
- p/n 14-578117-01 Accessory UHF Ant Cable TNC/Pole Mount, 12ft

1. For this type of antenna a metal surface, e.g. car's roof, serves as ground plane.

Configuration

GSM Antenna Installation
Connecting through serial port

2.3. GSM Antenna Installation

Attach the GSM antenna p/n 30-587314-01 to the SMA connector marked GSM.

Note: The GSM and RF antennas should be separated for about 1 meter to avoid the interference of GSM and UHF signals.

2.4. Installing AWLaunch

AWLaunch™ is a Windows® application for the radio modem configuration. AWLaunch is available from the ArWest Communications website.

Note: Refer to the *AWLaunch Software Manual* for full details on installing and using AWLaunch Software.

1. If downloading the program from the website, extract the program files into a folder on your hard drive.
2. Navigate to the location of the AWLaunch program and double-click the *AWLaunch.msi* icon.
3. Follow the on-screen installation wizard instructions. Click *Next* to continue, *Back* to get back to previous step, or *Cancel* to quit the installation.
4. Keep the default installation location or select a new location.
5. Click *Close* to complete the installation and quit wizard. If desired, create a shortcut on the computer's desktop for quick access to AWLaunch.

To uninstall AWLaunch use the *Add and Remove Programs* from the Control Panel.

1. Open the Control Panel, then *Add or Remove Programs* tool. Find *AWLaunch*, and click *Remove*. This will uninstall AWLaunch.

2.5. Connecting AW400BT with GSM and Computer

2.5.1. Connecting through serial port

To configure, or maintain AW400BT with GSM, you need to connect the modem and a computer using an Accessory Data-Ser-Pwr Cable, DB9/DB15/SAE (1,8m), p/n14-578108-02.



Figure 2-2. Accessory Data-Ser-Pwr Cables DB9/DB15/SAE

2.5.2. Connecting through USB port

Make sure the computer has special USB driver installed (available from www.arwestcom.com) before continuing. To configure, or maintain AW400BT with GSM using USB port, you need to connect the modem and a computer using special cable (not included in the standard kit) Access Data-Ser Cable, USB/DB15/SAE (1,8m) (p/n 14-578123-02).



Figure 2-3. Cable p/n 14-578123-01

1. Download the zip-archive with USB driver from www.arwestcom.com;
2. Extract the archive to the new empty folder;
3. Connect the USB port of the computer to the data port of the modem at the switched off power supply by using of a cable.
4. Turn on your computer.
5. Power AW400BT with GSM.
6. Windows will detect USB driver automatically. Otherwise it will ask to specify driver location. Select the folder with extracted file.

2.5.3. Connecting through Bluetooth®

The AW400BT with GSM modem contains Bluetooth® wireless technology that allows synchronization between the modem and any other external device that supports Bluetooth® wireless technology.

AW400BT with GSM and external device connection procedure varies slightly depending on the type of external device used. In general, the connection procedure is as follows:

Note: Refer to your Bluetooth®-enabled external device documentation for more detailed connection information.

1. Turn on a Bluetooth®-enabled external device and your receiver. The default external device mode is Master; the modem's Bluetooth® module mode is Slave.
2. Instruct the external device (Master) to search for the modem (Slave).
3. Once the Master device detects the modem, use the procedure described in the external device's documentation to connect it with the modem.

2.6. Configuring AW400BT with GSM

Once you have established a connection between the modem and the computer, you will be able to:

Configuration

Configuring AW400BT with GSM
Connecting through Bluetooth®

- Configure the modem and its components
 - Send commands to the modem
 - Use AWLaunch to load new firmware to the modem.
1. Connect the computer and AW400BT with GSM, as described in “Connecting AW400BT with GSM and Computer” on page 18.
 2. Turn on the AW400BT.
 3. Start AWLaunch.




Figure 2-4. Main window

4. Open the *Preferences* tab and select the COM port the modem is connected to (Figure 2-5), and click *Identify*.




Figure 2-5. Connect to AWLaunch

5. Once the identification process completed successfully unit's information will appear n the *Identification* subtab of *Configurations* tab (Figure 2-6 on page 22), i.e. serial number, firmware, hardware and boot loader versions.

Configuration

Configuring AW400BT with GSM

Connecting through Bluetooth®




Figure 2-6. Identification tab

- In the *Unit Name* text field the unit's name can be inserted;
 - In the *Owner* field the owner's name can be inserted.
6. In the *Configurations* ▶ *Wireless* sub tab set the parameters presented in Table 2-1 (Figure 2-7 on page 23).

Table 2-1. Modem Parameters for the Wireless Subtab

Parameter	Base Modem	Remote Modem	Repeater
Protocol	Base Select from the <i>List</i> Simplex Transmitter, Half Duplex, or PCC transmitter if Pacific crest protocol is used.	Remote Select from the <i>List</i> Simplex Receiver, Half Duplex Remote, or PCC Receiver if Pacific crest protocol is used.	Remote Select from the <i>List</i> Repeater, if the modem will be used as Repeater, or PCC Repeater, if Pacific crest protocol is used.
Frequency channel	Specifies the frequency channel on which the UHF radio operates.		
Modulation type	Specifies a modulation scheme that will be used by your modem ¹ . DQPSK is recommended.		
Forward Error Correction (FEC)	Enable		
Scrambling	Enable	Enable	
RF power	Select the transmission power for the radio modem in the RF modem slider, or type the value in the edit box		

1. For both Base and Remote modems the modulation type must be the same.




Figure 2-7. Configurations tab. Wireless subtab

7. In the *Dealer Configuration* set the channel spacing and fill in the channel map (the list of frequency channels). See Figure 2-8 on page 24.
The specified frequencies should be in band of 406-470 MHz.

Configuration

Configuring AW400BT with GSM
Connecting through Bluetooth®




Figure 2-8. Dealer Configuration tab

8. Configure Bluetooth in *Configurations* ▶ *Bluetooth* subtab.




Figure 2-9. Bluetooth subtab

- Enter PIN code
- Set state to ON
- Set the Mode to Slave.

Configuration

Configuring AW400BT with GSM
Connecting through Bluetooth®

9. Configure the Real Time Network in *Configurations* ▶ *RTN* subtab:




Figure 2-10. RTN subtab

10. Click *Download* button to download the configured settings into the radio modem.
11. Click *Save Config.* button to save the configuration settings on PC.
12. Click *Close* when finished.

2.6.1. Sleep Mode and Alarm settings

The sleep mode and alarm settings can be configured in the *Modem* subtab of the *Configurations* tab (Figure 2-11).




Figure 2-11. Configurations tab. Modem subtab

To configure the sleep mode set the period of inactivity in milliseconds and how the modem will be activated: using internal real-time clock, command line, or internal sense line.

The First and second Event Output control allow routing the alarms and the inputs from remote sensors to the first and second event outputs.

Note: This feature is not supported in current firmware version.

Configuration

Checking Firmware Version
Sleep Mode and Alarm settings

2.7. Checking Firmware Version

Use AWLaunch to check the firmware version of your AW400BT with GSM.

1. Select *Identification* subtab of *Configurations* tab;
2. Press *Identify* button (note that you may not press *Identify* button if identification process has been complete successfully once);




Figure 2-12. Identification subtab

This tab lists important information about the hardware accessories and software properties. This list includes the following, which you will need if you contact ArWest Communications or your dealer:

- Unit Type
 - Unit Name
 - Modem Serial Number
 - Firmware Version
 - BootLoader Version
 - Hardware Version
3. Click *Close* to quit AWLaunch.

2.8. Loading New Firmware

Use the latest firmware version, available for download from the ArWest website www.arwestcom.com, to ensure your modem has the most recent updates.

The AWLaunch software is used to load firmware into the modem. For more information, refer to the *AWLaunch Software Manual*, available on the ArWest website. To upgrade the firmware of radio modem the following steps must be performed:

1. Download the new firmware package to your computer.
2. Connect your modem to computer. See “Connecting AW400BT with GSM and Computer” on page 18 for this procedure.
3. Select *Download Firmware* subtab of *Utilities* tab;
4. Press *Identify* button (note that you may not press *Identify* button if identification process has been complete successfully once);
5. Press *Browse* button and select the firmware file which you want to download;
6. Press *Download* button (the downloading process may take a few minutes).




Figure 2-13. Download Firmware

7. Wait until the new firmware version loading will be complete.
8. Click *Close* to quit AWLaunch.

Configuration

Loading New Firmware

Sleep Mode and Alarm settings

INTERNET SERVICES

3.1. TCP client

TCP client service is used to receive RTN corrections from the specified TCP server via GPRS network. The downloaded RTN corrections are routed to the communication ports (UART, USB, BT) and/or broadcasted by UHF transmitter to multiple UHF receivers. Using this service it is possible to provide the local GPS receiver (connected to UART, USB or BT) and remote UHF receivers (for example the receivers which are not equipped with GSM/GPRS module) by downloaded RTN corrections simultaneously. To restart the TCP client after next boots automatically the RTN auto running feature can be used (refer to RTN AUTORUN command's description).

Example of TCP client configuration:

Let's assume we need to download RTN corrections from the TCP server which has the following parameters:

- IP address – 92.43.102.1;
- Port – 3615;
- Login – user;
- Password – pswd.

The TCP client should download corrections from TCP server, route them to UART and broadcast by UHF transmitter simultaneously. Suppose the parameters of UHF transmitter are as follows:

- Wireless protocol – ArWest Transmitter;
- Output power – 25 dBm;
- Modulation – DQPSK;
- Channel spacing – 25 kHz;
- Frequency channel – 1;
- Scrambling vector – 255.

The following is the step by step configuration of AW400BT to configure and run described TCP client:

Configure the UHF modem	LINK PROT 2 LINK PWRB 25 LINK MOD 2 LINK SPACE 0 LINK CHAN 1 LINK SCRAM 255
Select the TCP client as an active RTN service	RTN TYPE 0
Set the host name/IP address to connect	RTN HOSTNAME 92.43.102.1
Set the host port of remote machine	RTN HOSTPORT 3615

Internet services

TCP server

RTN corrections uploading

Set login and password to pass authentication on remote TCP server	RTN LOGIN user RTN PASSWORD pswd
Set data routing type to “GSMGPRS<->UART and GSMGPRS->UHF”	DPORT ROUTE 7
Start TCP client service	RTN CONNECT 1

The execution of “RTN CONNECT 1” command starts connecting process of TCP client and shows the progress of connecting. The following is the reported progress when the TCP client connected and authenticated on the host machine successfully:

```
RTN CONNECT 1
Connecting.....
Initializing GSM module.....
PIN code authentication..
Network registration.....
Activating GPRS context.....
Socket Dialing..
Connected, Authenticated
```

To start data routing the unit should be switched to data mode using “DATAMODE” command. Now to stop the running TCP client, the unit should be switched to command mode and “RTN CONNECT 0” command should be issued. The successful execution of this command reports the following progress and result:

```
RTN CONNECT 0
Disconnecting.....
Disconnected
@00
```

Note: If no data received from TCP server during 30 seconds the authorized TCP client disconnects from its server and starts reconnecting process.

3.2. TCP server

This service provides the following two features:

3.2.1. RTN corrections uploading

This feature is used to provide the authorized TCP clients by RTN corrections through the TCP channel using GPRS network. RTN corrections are taken from local GPS receiver (connected to UART, USB or BT) or from remote UHF transmitter and sent to the authorized TCP client.

3.2.2. Remote CLI support

TCP server also provides full functional Command Line Interface to the authorized TCP client. It means using the TCP server it is possible to configure and control the radio modem through the internet (by TCP client terminal at side of DTE). Configuration files upload/download and firmware image upgrading operations are also supported by remote CLI feature provided by TCP server. The CLI is shared with authorized TCP client when the unit is in command mode.

The RTN command is used to configure, control and monitor the TCP server. To start the TCP server after next boots automatically the RTN auto running feature can be used (refer to RTN AUTORUN command's description). It means that BOOT command issued by Remote CLI will not disconnect the Remote CLI permanently if the unit is configured to start TCP server automatically after next boot. The client terminal can connect to the TCP server again after unit's rebooting.

Example 1 of TCP server configuration – RTN corrections uploading:

Let's assume we need to upload RTN corrections (taken from UART) to authorized TCP client using TCP server:

- Server should be running on the 3615 port of assigned IP address (IP address is assigned by GPRS network);
- Login – user;
- Password – pswd.

The following is the step by step configuration of AW400BT with GSM to configure and run described TCP server:

Select TCP server as an active RTN service	RTN TYPE 2
Set the host port on which the server should be run	RTN HOSTPORT 3615
Set the login and password which are used for TCP client's authorization	RTN LOGIN user RTN PASSWORD pswd
Set data routing type to "GSMGPRS<->UART"	DPORT ROUTE 4
Start/run the configured TCP server	RTN CONNECT 1

The execution of "RTN CONNECT 1" command starts TCP server and shows the progress of starting process.

The following is the reported progress when the TCP server is run successfully:

```
RTN CONNECT 1
Connecting.....
Initializing GSM module.....
PIN code authentication..
Network registration.....
Activating GPRS context.....
Starting server..
Server is running
```

At this point the server is running and waits for authorized TCP client. Now the unit should be switched to data mode to start RTN corrections uploading when the TCP client is connected and authorized.

Internet services

NTRIP client

Remote CLI support

```
RTN CONNECT 0
Disconnecting.....
Disconnected
●@00
```

Example 2 of TCP server configuration – Remote CLI support:

Let's assume we would like to configure the AW400BT with GSM remotely - through the internet. We can do it using Remote CLI support provided by TCP server service. The following is the step by step configuration of AW400BT with GSM to run TCP server in such mode (the login, password and host port are the same as in Example 1 above).

Select TCP server as an active RTN service	RTN TYPE 2
Set the host port on which the server should be run	RTN HOSTPORT 3615
Set the login and password which are used for TCP client's authorization	RTN LOGIN user RTN PASSWORD pswd
Start/run the configured TCP server	RTN CONNECT 1

The execution of "RTN CONNECT 1" command starts TCP server and shows the progress of starting process. The following is the reported progress when the TCP server is run successfully:

```
RTN CONNECT 1
Connecting.....
Initializing GSM module.....
PIN code authentication..
Network registration.....
Activating GPRS context.....
Starting server..
Server is running
```

At this point the TCP server is running and waits for authorized TCP client to provide remote CLI. To get the IP address on which the TCP server is running the RTN HOSTNAME command can be used.

Note: Currently the TCP server is able to serve one TCP client.

Note: TCP server is restarted if the connection with the client is closed.

●

3.3. NTRIP client

This service is used to receive RTN corrections from specified Mount point of the specified NTRIP caster via GPRS network. The downloaded RTN corrections are routed to the communication ports (UART, USB, BT) and/or broadcasted by UHF transmitter to multiple UHF receivers. Using this service it is possible to provide the local GPS receiver (connected to UART, USB or BT) and remote UHF receivers (for example the receivers which are not equipped with GSM/GPRS module) by downloaded RTN corrections simultaneously. If the NMEA GGA is required by remote NTRIP caster, the NTRIP client can

be configured to send the NMEA GGA messages to NTRIP caster taking NMEA from the local GPS receiver (connected to the UART, USB or BT) or using predefined NMEA GGA message saved in the configuration file. The RTN command is used to configure, control and monitor the NTRIP client service. To start the NTRIP client service automatically after next boot the RTN auto running feature can be used (refer to “RTN AUTORUN” command’s description).

Example of NTRIP client configuration:

Let’s assume we need to download RTN corrections from NTRIP caster which has the following parameters:

- IP address - 78.43.52.12;
- Port – 2101;
- Mount point AUT10;
- Login – user;
- Password – pswd;

NMEA GGA messages are required by NTRIP caster.

Suppose the NTRIP client should read the NMEA GGA messages from USB, send them to NTRIP caster then download RTN corrections from caster and route them to USB port.

The following is step by step configuration of AW400BT to configure and run described NTRIP client service.

Select the NTRIP client as an active RTN service	RTN TYPE 1
Set the host name/IP address to connect	RTN HOSTNAME 78.43.52.12
Set the host port of remote machine	RTN HOSTPORT 2101
Set login and password to pass authentication on remote NTRIP caster.	RTN LOGIN user RTN PASSWORD pswd
Set the Mount point	RTN MPOINT AUT10
Set data routing type to “GSMGPRS<->USB”	DPORT ROUTE 5
Disable the predefined NMEA GGA messages (the NMEA GGA messages are read from USB port)	RTN NMEA NONE
Start NTRIP client service	RTN CONNECT 1

The execution of “RTN CONNECT 1” command starts connecting process of NTRIP client and shows the progress of connecting. The following is the reported progress when the NTRIP client connected and authenticated on the host machine successfully:

```
RTN CONNECT 1
Connecting.....
Initializing GSM module.....
PIN code authentication..
Network registration.....
Activating GPRS context.....
Socket Dialing..
Connected, Authenticated
```

After successful authentication the unit should be switched to data mode to start data routing as it is configured.

Internet services

NTRIP client

Remote CLI support

Now to stop the running NTRIP client service, the unit should be switched to command mode and “RTN CONNECT 0” command should be issued. The successful execution of this command reports the following progress and result:

```
RTN CONNECT 0
Disconnecting.....
Disconnected
@00
```

Note: If no data received from NTRIP caster during 30 seconds the authorized NTRIP client disconnects from its caster and starts reconnecting process.

Note: The IP address, host port, user name and login parameters in the examples above are invented. These parameters should be taken from RTN provider.

Note: In the examples above it is assumed that the GPRS Access point name, login and password are already configured.

COMMAND LINE INTERFACE

The built-in user friendly Command Line Interface (CLI) allows user performing full configuration of the unit and reading the statistics and alarm statuses. It is the most powerful tool to configure the unit. It makes changes to all possible settings that system will not be able to determine automatically.

The CLI commands allow user configuring and reconfiguring the unit's settings. The user configuration parameters that could be changed through the CLI are:

- Data Port Settings
 - Baud Rate
 - Flow control (None or RTS/CTS)
- Radio Operation Modes

Note: The unit's configuration that is set or modified through the CLI will be lost after unit's reboot, unless the saving operation is used to store a new setting in the unit's configuration file.

The CLI commands also provide filling operations, which include:

- Downloading
 - Unit's Configuration files
 - Software Images
- Uploading Unit's Configuration files
- Saving into the configuration files the configuration parameters modified through the CLI.

4.1. Command Line Interface Convention

The following convention is implemented in AW400BT with GSM Command Line Interface (CLI):

- The Carriage Return/Line Feed (CR/LF, 0x0D/0x0A) is a command delimiter.
- The Carriage Return/Line Feed (CR/LF, 0x0D/0x0A) is a reply delimiter followed by the "CLI>" prompt if Echo option is On.
- The Carriage Return/Line Feed (CR/LF, 0x0D/0x0A) is a reply delimiter if Echo option is Off (default option).
- The 2-digit number followed by "@" in the unit's reply indicates the error code (refer to Table 4-1 for description).
- A successfully performed command is replied by @00 code for both Echo ON and OFF modes.
- A command with the certain [*Parameter Name*] and blank [*Parameter List*] displays the current settings for a given parameter.

Command Line Interface

Command Line Interface Convention
Software Switching to Maintenance Mode

- To set the mode ordered by CLI commands as permanent User Setting (the setting automatically selected for the boot-up unit) the SAVE command must be asserted.
- [/?] orders to show the help information for the given command.
- Commands are not case sensitive (unless the GSM and RTN commands): small, none capital characters can be used to enter CLI commands.

Table 4-1. Command Line Interface Error Codes

Error Code	Short Description
0x01	Command Syntax Error. A command followed by “/?” displays a command usage.
0x02	The parameter has a format error. A command with the certain [Parameter Name] followed by “/?” displays the format and range of the variable.
0x03	The parameter is out of allowed range or it is not allowed to change in the current operation mode. A command with the certain [Parameter Name] followed by “/?” displays the format and range of the variable.
0x04	The command is not valid for specific radio model. To display the list of available commands, the HELP command must be used (see “Software Switching to Maintenance Mode”).
0x05	Unspecified Error
0x06	Operation is not allowed
0x07	Operation failed

4.1.1. Software Switching to Maintenance Mode

To switch to Maintenance mode the special byte-sequences with special meanings are used:

- Escape-Sequence: “+++” with 20 ms guard time before and after the command characters
- Escape-Acknowledge: “@00<CR><LF>” 20 ms toggling on CTS control line needed to acknowledge switching from Data to Maintenance mode and vice versa. In Maintenance mode, the unit’s serial port must keep CTS line always active.

Happy Flow

1. In data-mode the unit starts looking for the Escape-sequence if there is no data from DTE for more than 20 ms (Start Guard Time).
2. If the unit detects the Escape-Sequence, the Receiver immediately stops forwarding to DTE the data received over the air and buffers it instead.
3. The radio unit waits for 20 ms and then sends Escape-Acknowledge to DTE if there is no data from DTE during 20 ms of Stop Guard Time.
4. The unit goes to Maintenance mode and discards Escape-Sequence from input buffer. The modem is immediately ready to receive commands. At the same time it continues buffering the data received over the air since step 2.

4.1.2. Hardware Switching to Maintenance Mode

As alternative to Software Switching, the switching through the MP/DP control line can be used (this control line can be also used as Data Terminal Ready, DTR). To set Maintenance mode, the DTE must assert DTR signal active (0v level). By falling edge of DTR signal the unit goes to Maintenance mode and then sends Escape-Acknowledge to DTE („@00<CR><LF>“).

20 ms toggling on CTS control line followed by Escape-Acknowledge response is needed to acknowledge switching from Data to Maintenance mode and vice versa. In Maintenance Mode, the unit's serial port must keep Clear to Send (CTS) line always active (see also “MPORT” on page 42).

Note: The powered up radio modem always goes to data mode.

4.1.3. Switching to Data Mode

- DTE sends the CLI command „DATAMODE<CR><LF>“ to the unit.
- Unit immediately goes to data mode without Escape Acknowledge.
- If no valid CLI commands received from DTE within 1 minute, the unit will automatically switch back to data-mode.

Note: The data received over the air could be lost due to Rx buffer overflow if the unit stays in Maintenance mode longer than 15 seconds.

4.2. Networking Commands

4.2.1. LINK

The LINK command is responsible for configuring radio's operation mode. It has parameters listed below.

LINK [*Parameter Name*] [*Parameters List*] [/?]

Command Line Interface

Networking Commands

LINK

Parameter Name	Parameter List
PROT	1 - "Simplex Receiver", a default setting for Remote units 2 - "Simplex Transmitter" 3 - Reserved for future use 4 - Reserved for future use 5 - Reserved for future use 6 - Reserved for future use 7 - "TRMB Receiver" (used with GMSK modulation, Trimble compatible) 8 - "TRMB Transmitter" (used with GMSK modulation, Trimble compatible) 9 - "Transparent w/EOT" Repeater (used with GMSK and 4FSK, Pacific Crest compatible) 10 - "Repeater" (ArWest Proprietary Simplex) 11 - "TRMB Repeater" (used with GMSK modulation, Trimble compatible) 12 - "Transparent w/EOT" Receiver (used with GMSK and 4FSK modulation, Pacific Crest compatible) 13 - "Transparent w/EOT" Transmitter (used with GMSK and 4FSK modulation, Pacific Crest compatible) 14 - "STL Receiver" (used with 4FSK modulation, Satel compatible) 15 - "STL Transmitter" (used with 4FSK modulation, Satel compatible)
MOD	1 - DBPSK 2 - DQPSK, a default settings 3 - D8PSK 4 - D16QAM 5 - GMSK 6 - 4FSK
CHAN	1-32 - Selects the frequency channel used for UHF data receiving operation. The maximum value is defined by number of frequencies in the channel map.
CHANTX	1-32 - Selects the frequency channel used for UHF data transmitting operation. The maximum value is defined by number of frequencies in the channel map.
SPACE	Sets channel spacing: 0 - 25kHz, a default setting 1 - 12.5kHz 2 - 6.25kHz 3 - 20kHz
PWRB / PWRW	(15 - 36) / (320 - 4000) - RF output Power in dBm / mW
FHOP	(0 - 32) - Frequency Hopping Pattern number LINK FHOP command can be processed only if the Channel Map (up to 32 channels)
SCRAM	0 - No Scrambling (a default setting) (1 - 255) - Seed for Pseudo-Random Sequence Generator
FEC	0 - Disable Forward Error Correction (FEC), a default setting 1 - Enable Reed-Solomon encoding
RTR	Base Unit 0 - No Retransmission in the wireless cluster 1 - There is Repeater Remote Unit 0 - Auto Detect (Base or Repeater) 1 - Receive from Repeater 2 - Receive from Base

Note: The frequency defined by CHAN parameter is not valid if Frequency Hopping mode is selected.

In the Frequency Hopping mode, the Frequency Pattern generator must generate the random numbers smaller than the number of frequencies listed in the unit's frequency list.

4.3. Serial Interfacing Commands

4.3.1. DPORT

The DPORT is an object that is responsible for data port interface configurations like Bit Rate, Flow Control, etc.

DPORT [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
RATE	0 – Maintenance Port baud rate, a default setting 1 – 1200 baud 2 – 2400 baud 3 – 4800 baud 4 – 9600 baud 5 – 14400 baud 6 – 19200 baud 7 – 38400 baud 8 – 57600 baud 9 – 115200 baud, a default setting
BITS	Set number of bits in one byte (8 or 7) 8 is a default setting
PARITY	0 – None, a default setting 1 – Odd 2 – Even
FLOW	0 – None, a default setting 1 – Not used 2 – HW (RTS/CTS)
RS	0 - RS232, a default setting 1 - RS485 2 - RS422 use save, boot commands to activate modification
ROUTE	Sets/gets the data routing type. The following is the list of parameter values: 1 - UART<->UHF bidirectional 2 - USB<->UHF bidirectional 3 - BT<->UHF bidirectional 4 - UART<->GSM/GPRS bidirectional 5 - USB<->GSM/GPRS bidirectional 6 - BT<->GSM/GPRS bidirectional 7 - UART<->GSM/GPRS bidirectional & GSM/GPRS->UHF one directional 8 - USB<->GSM/GPRS bidirectional & GSM/GPRS->UHF one directional 9 - BT<->GSM/GPRS bidirectional & GSM/GPRS->UHF one directional 10 - GSM/GPRS<->UHF bidirectional.

The response of command without *Parameter Name* indicates all values:

```
RATE =0
BITS =8
PARITY =NONE
FLOW =NONE
DTR =0
RS =RS232
ROUTE = 1
```

Command Line Interface

Special Commands

MPORT

4.3.2. MPORT

The MPORT is an object that is responsible for maintenance serial port interface configuration such as data rate.

MPORT [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
RATE	0 – Auto. 1 – 1200 baud 2 – 2400 baud 3 – 4800 baud 4 – 9600 baud 5 – 14400 baud 6 – 19200 baud 7 – 38400 baud 8 – 57600 baud 9 – 115200 baud, a default setting

4.4. Special Commands

4.4.1. BOOT

The BOOT command is intended to reboot the unit using selected user settings.

4.4.2. HELP

The HELP command types the list of all available commands:

```
HELP - Display this usage
XMOD - Activate X-Modem Protocol
BOOT - Reboot the unit
LINK - Set RF Link Operation Mode
DPORT - Set Data Port Configuration
MPORT - Set Maintenance Port Configuration
ALARM - Alarm Indication and Alarm Control Configuration
SLEEP - Set Sleep Mode Configuration
STATE - Display Status and Statistics
SAVE - Save Current Configuration into Configuration File
INFO - Display Product ID along with Hardware/Software Versions
ATI - Display Product ID along with Hardware/Software Versions
MAP - Operates with Channel Map
GSM - Configure and monitor GSM/GPRS module operation mode
RTN - Configure and monitor Virtual reference station operation mode
```

DATAMODE - Exit Command Mode

[COMMAND] /? - Display Command Usage

4.4.3. SAVE

The SAVE command is intended to store the unit’s currently used configuration into the User Configuration file. The configuration stored in the User Configuration file is activated automatically after unit’s reboot.

4.4.4. SLEEP

The SLEEP command determines the sleep mode parameters. The sleeping AW400BT with GSM can be activated by real-time CLK, DTR/RTS lines, and command received through TTL inputs. The user can select one, two, or all three conditions.

SLEEP [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
CLK	0 – Do not activate by internal real-time clock (1 – 255) – Activate by internal real-time clock after 100 to 25500 msec of sleeping
HW	0 – Do not activate through DTR/RTS lines 1 – Activate through DTR/RTS lines
TTL	0 – Do not activate by external sense lines 1 – Activate by external sense lines
GTS	0 – Disable Sleep mode (default) (1 – 255) – Go to sleep mode if there is no activity in 10 to 2550 msec

Command Line Interface

Diagnostics and Identification Commands

INFO

4.5. Diagnostics and Identification Commands

4.5.1. INFO

The INFO command is used to retrieve the Radio ID along with its Hardware version, the loaded real-time software version/revision and BootLoader's version/revision.

INFO [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
ID	Product ID: ID49 - AW400BT_GSM
SN	Six bytes Serial Number (SN)
HW	1.0 - hardware version in numeric "Major.Minor" format
SW	Ver. 1.0 Rev. A - displays software's version in numeric "Major.Minor" format and revision in numeric format (range from 01 to 99) for engineering releases and alphabetic format (A to Z) for manufacturing releases
BL	Ver. 1.0 Rev. A - displays BootLoader's version in numeric "Major.Minor" format and revision in numeric format (range from 01 to 99) for engineering releases and alphabetic format (A to Z) for manufacturing releases
BT	Bluetooth serial number

The INFO command without *Parameter Name* indicates all values:

```
AW400BT UHF Transceiver, ArWest
Product ID =49
S/N =0000000123BB
Hardware =Ver. 3.3
Software =Ver. 1.8 Rev 04 B24
BootLoader =Ver. 3.0 Rev 03
BT addr =00:18:D7:00:3C:C7
```

4.5.2. STATE

The STATE command is used to check the state of the wireless link and the alarm control lines.

STATE [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
RSSI	-15 to -137 dBm - Indicates the Receive Signal Strength in dBm
BER	0 to 9.9E-3 - Indicates the BER level
FREQ	406.000000 to 470.000000 MHz - Displays the central frequency of the operating channel
TEMP	-30.C to 100.C. Displays the temperate inside of enclosure.

Parameter Name	Parameter List
SYNC	0 - if link is not established yet 1 - indicates the link established
MODE	AUTO/FHOP/FIXED
VHPA	VCC V
BT	ON/OFF

The STATE command without *Parameter Name* indicates all values as shown below:

```

RSSI =-141 dBm
BER =0E-0
FREQ =435.000000 MHz
CHAN =-4
TEMP =32
SYNC =0
MODE =FIXED
VHPA =11.75 V
BT =ON
    
```

4.6. RTN

Command RTN is used to select, configure, control and monitor the active Real Time Network. Except the monitoring parameters (STATE and ERROR) all the parameters of RTN services can be saved in the user configuration file by SAVE command.

Parameter Name	Description and parameters list
TYPE	<p>Sets/gets the active RTN service: 0 – TCP client; 1 – NTRIP client; 2 – TCP server. Example: the next command selects NTRIP client as an active RTN service to be configured, controlled and monitored: RTN TYPE 1 The next command is used to get currently selected active RTN service: RTN TYPE 1 @00</p>
CONNECT	<p>Starts/stops the active RTN service. 0 – Stops/disconnects the active RTN service if it is running; 1 – Starts/connects the active RTN service if it is stopped. There is a 50-70 seconds and 15 seconds timeouts for start and stop processes correspondingly. If during this timeout the start/stop operation is not succeeded the operation is failed and the last error is monitored by RTN ERROR command. Example: the next command starts the active RTN service: RTN CONNECT 1</p>

Command Line Interface

RTN
STATE

HOSTNAME	<p>Sets/gets the string type value representing the host name/IP address of the active RTN service. In case of TCP/NTRIP clients this is the IP address/host name of the remote machine to connect. In case of TCP server this parameter is read only and represents its own IP address assigned by GPRS network.</p> <p><value> – string (length < 64 bytes).</p> <p>Example: next command sets the IP address of the host to connect RTN HOSTNAME 92.43.102.1 Next command gets the currently set IP address of the active RTN: RTN HOSTNAME 92.43.102.1 @00</p>
HOSTPORT	<p>Sets/gets the decimal numeric value representing the host port of the active RTN service. In case of TCP/NTRIP clients this is the port of remote machine to connect. For TCP server this is the port on which the server is listening for incoming connections.</p> <p><value> - port number (1..65535).</p> <p>Example: next command sets the host port of active RTN service: RTN HOSTPORT 3615 Next command gets the currently set host port of the active RTN service: RTN HOSTPORT 3615 @00</p>
MPOINT	<p>Sets/gets the string type value representing the Mount point for NTRIP client to connect. This parameter is not applicable for TCP client/server services. To set this parameter the NTRIP client should be selected as an active RTN service by RTN TYPE command.</p> <p><value> – string (length < 64 bytes).</p> <p>Example: next command sets the Mount point for NTRIP client to connect: RTN MPOINT AUT10 The next commands gets the Mount point of NTRIP client: RTN MPOINT AUT10 @00</p>
NMEA	<p>Sets/gets the string type value representing predefined NMEA GGA message to use in NTRIP client service. This parameter is not applicable for TCP client/server services. To set this parameter the NTRIP client should be selected as an active RTN service by RTN TYPE command.</p> <p><value> – string (length < 128 bytes).</p> <p>If the value represents any string different from NONE the authorized NTRIP client uses this predefined message and sends it to NTRIP caster once a second.</p> <p>If the value is set to NONE the NTRIP client does not send predefined NMEA GGA message to NTRIP caster.</p> <p>Example: next command sets/defines the NMEA GGA message for NTRIP client: RTN NMEA 1234567890 The next command gets the currently set NMEA parameter of NTRIP client: RTN NMEA 1234567890 @00</p>
LOGIN	<p>Sets/gets the string type value representing the login (user name) of the active RTN service. For TCP/NTRIP clients this parameter is used to pass authorization on the remote machine. For TCP server this parameter is used to identify the authorized TCP clients.</p> <p><value> - string (length < 64 bytes).</p> <p>Example: next command sets the login of the active RTN service to “user” RTN LOGIN user Next command gets the currently set login of the active RTN service: RTN LOGIN user @00</p>

PASSWORD	<p>Sets/gets the string type value representing the password of the active RTN service. For TCP/NTRIP clients this parameter is used to pass authorization on the remote machine. For TCP server this parameter is used to identify the authorized TCP clients. <value> - string (length < 64 bytes). Example: next command sets the password of the active RTN service to “pswd” RTN PASSWORD pswd</p> <p>Next command gets the currently set password of the active RTN service: RTN PASSWORD pswd @00</p>
TRANSPORT	<p>Gets the transport of the RTN service used to access the internet. This parameter is read only and returns GPRS. Example: next command gets the transport of RTN services RTN TRANSPORT GPRS @00</p>
STATE	<p>Gets the state of active RTN service. This parameter is used for monitoring purposes. Example: next command is used to get the state of active RTN service RTN STATE Authenticated @00</p>
ERROR	<p>Gets the description of last error occurred in the active RTN service. This parameter is used for monitoring purposes. Example: next command gets the last error occurred in the active RTN service RTN ERROR None</p>
AUTORUN	<p>Sets/gets the auto running state of the RTN service. 0 – Disables auto running of active RTN service for next boots; 1 – Enables auto running of active RTN service for next boots. To take effect the parameter should be saved in the configuration file using SAVE command.</p>

Note: The internet service can be configured in its stopped/disconnected state only.

Note: The RTN command is case sensitive to support possible case sensitive string type values of its parameters.

4.7. GSM

GSM command is used to configure, control and monitor the built in Quad band GSM/GPRS module.

Parameter name	Parameter list and description
BAND	<p>Sets/gets the operating frequency band of GSM/GPRS module: 0 - GSM 900MHz, DCS 1800MHz; 1 - GSM 900MHz, PCS 1900MHz; 2 - GSM 850MHz, DCS 1800MHz; 3 - GSM 850MHz, PCS 1900MHz. Example: next command sets the operating frequency band of GSM/GPRS module to “GSM 900MHz, DCS 1800MHz”. GSM BAND 0 Next command gets the current operating frequency band of GSM/GPRS module: GSM BAND GSM 900MHz, DCS 1800MHz @00</p>

Command Line Interface

GSM
STATE

RSSI	<p>Gets the received signal level of GSM/GPRS module which is used for monitoring purposes. <response> – N/A – the GSM/GPRS module switched OFF or signal quality is not recognized; Not known – the received signal level of GSM/GPRS module is not detected yet; Value of received signal level in dBm.</p> <p>Example: next command gets the current received signal level of GSM/GPRS module. GSM RSSI -79 dBm @00</p>
PINCODE	<p>Sets/gets the string type value representing the PIN code of the SIM card installed. PIN code is used by firmware to unlock the SIM card if it is requested. Otherwise the parameter is ignored. <value> - string (length < 64 bytes).</p> <p>Example: next command sets the PIN code to “1111” to unlock the SIM card by firmware. GSM PINCODE 1111 Next command gets the currently set PINCODE parameter: GSM PINCODE 1111 @00</p>
APN	<p>Sets/gets the string type value representing the Access Point Name of GPRS which is used to access the internet. <value> - string (length < 64 bytes).</p> <p>Example: next command sets the APN to “connect” GSM APN connect Next command gets the currently set APN: GSM APN Connect @00</p>
APNLOGIN	<p>Sets/gets the string type value representing the login (user name) which is used in the authorization process at access point site of GPRS. <value> - string (length < 64 bytes).</p> <p>Example: next command sets the login to “user” GSM APNLOGIN user Next command gets the currently set login: GSM APNLOGIN user @00</p>
APNPASSWORD	<p>Sets/gets the string type value representing the password which is used in the authorization process at access point site of GPRS. <value> - string (length < 64 bytes).</p> <p>Example: next command sets the password to “pswd” GSM APNPASSWORD pswd Next command gets the currently set password: GSM APNPASSWORD pswd @00</p>
POWER	<p>Sets/gets the power of GSM/GPRS module. 0 – switches OFF the module if it is ON; 1 – switches ON the module if it is OFF.</p> <p>Example: next command switches ON the power of GSM/GPRS module GSM POWER 1 Next command gets the power of GSM/GPRS module: GSM POWER 1 @00</p>

Note: The GSM command is case sensitive to support possible case sensitive string type values of its parameters.

SPECIFICATIONS

A.1. AW400BT with GSM Modem Specifications

The following sections provide specifications for the modem and its internal components.

A.1.1. General Radio Specifications

Table A-1. General Radio Specifications

Parameter	Specification
Operating Frequency Range	406 - 470 MHz (EU) 406.1 - 470 MHz (USA) 406.1 - 430;450-470 MHz (Canada)
Channel Spacing	25/12.5/6.25 kHz (USA, Canada) 25/20/12.5 kHz (EU)
Data Rate (25/20/12.5/6.25 kHz Channel Spacing)	9600/7500/4800/2400 bps – DBPSK/GMSK 19200/15000/9600/4800 bps – DQPSK/4FSK 28800/22500/14400/7200 bps – D8PSK 38400/30000/19200/9600 bps – D16QAM
System Gain for DBPSK modulation (Antenna gain is not included)	161 dB (for 25 kHz Channel Spacing) 163 dB (for 12.5 kHz Channel Spacing) 164 dB (for 6.25 kHz Channel Spacing)
Roaming Speed for DBPSK modulation	75 mph / 120 km/h
Modulation	GMSK/4FSK/DBPSK/DQPSK/D8PSK/D16QAM
Nominal Impedance	50 Ohms
End to End delay	60 ms
Communication Mode	Time Division Duplex (TDD) Time Division Multiple Access (TDMA)
Maximum Distance Range	16 miles / 26 km
Serial port	Serial (RS-232) up to 115200 bps. Serial port configurable as RS-232 and RS-422, or RS-485
USB	USB 2.0 device port (12 Mbps)
GSM/GPRS Module	Internal GSM/GPRS quad-band module 850/900/1800/1900 MHz
GSM/GPRS Antenna	External
Bluetooth	Bluetooth V2.0 Class 2 supporting SPP Slave and Master Profiles
Bluetooth Antenna	Embedded

Specifications

AW400BT with GSM Modem Specifications
Environmental Specifications

A.1.2. Environmental Specifications

Table A-2 lists the modem's environmental specifications.

Table A-2. Environmental Specifications

Parameter	Specification
Temperature	Operating -40°C to $+60^{\circ}\text{C}$ Storage -40°C to $+85^{\circ}\text{C}$
Environmental	IP 66
Dimensions (H x W x D)	146 mm x 75 mm x 44 mm
Weight	488 g
Power Supply Voltage	+9 to +36 VDC nominal
Power Consumption (Average)	18W / 2W / 0.01W –Transmit / Receive / Sleep
Housing/Color	Aluminum / Two-tone ArWest Green / Gray
UHF Antenna Connector	TNC, 50Ω
GSM Connector	SMA

A.1.3. Transmitter Specifications

Table A-3 lists the transmitter specifications.

Table A-3. Transmitter Specifications

Parameter	Specification
Output Power USA, Canada	15 dBm to 36 dBm in 1 dB steps (32mW to 4W)
EU	15 dBm to 33 dBm in 1 dB steps (32mW to 2W)
Output Power Control Accuracy	± 1.5 dB (at normal test conditions)
Carrier Frequency Stability	± 1.5 ppm initial stability over temp with ± 3.0 ppm aging/year
Max. Frequency Error	± 1.0 kHz (at normal test conditions) ± 1.5 kHz (under extreme test conditions)
Adjacent Channel Power (Conducted) 25/12.5/6.25 kHz CS USA, Canada 25/20/12.5 kHz CS EU	Part §90.210 (C, D, E) Clause 4.2.4 EN 300 113-2 (60 dBc)
Spurious Emission (Conducted)	-36 dBm (9 kHz – 1GHz) -30 dBm (1GHz – 4 GHz)
Spurious Emission (Radiated)	-36 dBm (9 kHz to 1 GHz) -30 dBm (1 GHz to 4 GHz)

A.1.4. Receiver Specifications

Table A-4 lists the receiver specifications.

Table A-4. Receiver Specifications

Parameter	Specification
Noise Figure	3 dB
Receiver Sensitivity (BER 1x10 ⁻⁴ , 25 kHz CS)	DBPSK -116 dBm 25kHz / -117 dBm 12.5kHz DQPSK -115 dBm 25kHz / -116 dBm 12.5kHz D8PSK -110 dBm 25kHz / -111 dBm 12.5kHz D16QAM -106 dBm 25kHz / -107 dBm 12.5kHz GMSK -113 dBm 25kHz / -114 dBm 12.5kHz
Dynamic Range	-115 to -15 dBm
Max. Input Signal Level	-10 dBm
Co-channel Rejection	-8 dB for 25 kHz Channel Spacing -12 dB for 12.5 kHz Channel Spacing -16 dB for 6.25 kHz Channel Spacing
Adjacent Channel Selectivity	70 dB for 25 kHz Channel Spacing 60 dB for 12.5 kHz Channel Spacing 50 dB for 6.25 kHz Channel Spacing

Specifications

Internet Services
Receiver Specifications

A.2. Internet Services

Parameter	Specification
TCP server	Runs a TCP server on the specified port of the hostname/IP provided by cellular network operator, accepts the connection from authorized TCP client, and uploads data receiving from RF interface (from a UHF transmitter) or communication ports (UART, USB or Bluetooth) to the connected TCP client. TCP server provides the authorized TCP client by Remote CLI feature also.
TCP Client	Connects to the specified TCP server, downloads data from it, modulates with supported modulation types and transmits at RF output power levels from 15 dBm up to 36 dBm operating in UHF frequency band (406 to 470 MHz). The downloaded data can be routed to the UART, USB or Bluetooth communication ports also.
NTRIP Client	Connects to the specified NTRIP caster and Mount point, downloads data from NTRIP caster and routes it as for TCP client service described above. The NTRIP client is also able to take NMEA GGA messages from UART, USB or Bluetooth communication ports and upload it to the NTRIP caster.

A.3. Compliance

Parameter	Specification
FCC	Part 90
Industry Canada	RSS-119
R&TTE	ETSI EN 300 113-2; ETSI EN 301 489-5; EN 60950-1:2006

A.4. Connector Specifications

DB15 Connector

This provides DB15 connectivity for the AW400BT with a DB9 for connection to a PC/CE Device for configuration.




Figure A-1. DB15 Connector

This connector provides DB15 connectivity for the AW400BT with DTE. About using and configuration RS-485 please contact ArWest support.

Table A-5. DB15 Connector Specifications

Number	Signal Name	Dir	Details
1	DCD_OUT	O	Data Carrier Detect (RS-232)
2	DTR_OUT	O	Data Terminal Ready (RS-232)

Number	Signal Name	Dir	Details
3	RX+/CTS_IN	I	Receive Data positive line (RS-422/RS485)/Clear to Send (RS-232)
4	RX-/RX_IN	I	Receive Data negative line (RS-422/RS485)/Receive Data (RS-232)
5	PWR_IN	I	+9 to +36 VDC Power Input
6	USB_PWR	I	Power Input line (USB)
7	Ground	-	Power Ground
8	PWR_IN	I	+9 to +36 VDC Power Input
9	DSR_IN	I	Data Set Ready (RS-232)
10	TX+/RTS_OUT	O	Transmit Data positive line (RS-422/RS485) /Request to Send (RS-232)
11	TX-/TX_OUT	O	Transmit Data negative line (RS-422/RS485) / Transmit Data (RS-232)
12	Ground	-	Power Ground
13	USB_D+	I/O	Positive line (USB)
14	USB_D-	I/O	Negative line (USB)
15	Ground	-	Power Ground

External Antenna RF Connector

The external antenna connector type is a TNC RF connector AEP Connectors 6001-7051-003.

GSM Antenna Connector

GSM Antenna Connector is a standard SMA connector.

Specifications

Connector Specifications

Receiver Specifications

UHF RADIO USAGE

Many countries require a license for radio users (such as the United States of America). Be sure you comply with all local laws while operating a UHF radio.

Surveying in RTK mode has made UHF the most popular choice for communications between base and rover receivers. Know the strengths and weaknesses of this technology to get the best use out of your receiver.

The quality and strength of the UHF signals translates into range for UHF communications.

The system's range will greatly depend on the local conditions. Topography, local communications and even meteorological conditions play a major role in the possible range of RTK communications.

If needed, use a scanner to find clear channels for communication.

UHF Radio Usage

SAFETY WARNINGS

Read these instructions.

- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Clean only with a damp cloth.
- Do not block any of the ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, or has been dropped.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, shall be placed on the apparatus.

Safety Warnings

General Warnings

C.1. General Warnings

AW400BT with GSM is a wireless device used in a mobile application, at least 100 cm from any body part of the user or nearby persons.

Note: Minimum separation distance of 100 cm between the antenna and persons must be maintained.

This product should never be used:

- Without the user thoroughly understanding operator's manual.
- After disabling safety systems or altering the product.
- With unauthorized accessories.
- Contrary to applicable laws, rules, and regulations.

DANGER: THE AW400BT WITH GSM SHOULD NEVER BE USED IN DANGEROUS ENVIRONMENTS.

WARRANTY TERMS

ArWest Communications Corp., Inc. (“Company”) warrants, to the end-user only, that the Narrow Band Radio Modems (“Radios”) purchased (a) conforms to the Company’s published specifications for the model purchased, and (b) is free from defects in material or workmanship. The duration of this warranty is twelve (12) months¹ from date of purchase and any claim for breach of warranty must be brought to the Company’s attention within such twelve (12) month period and the Receiver must be returned for action on any such claim within twelve (12) months from the date of purchase. Within a reasonable period of time after a claim, the Company will correct any failure of the Radio to conform to specifications or any defect in materials or workmanship, or replace the Radio, or, at its option, provide a full refund of the purchase price. A repaired or replaced product is warranted for 90 days from the date of return shipment to the buyer, or for the balance of the original warranty period, whichever is longer. These remedies are the buyer’s exclusive remedies for breach of warranty.

To obtain warranty service, the buyer must return the Radio, postage-paid, with proof of the date of original purchase and the buyer's return address to the Company or an authorized service center. The Company will not be responsible for any loss or damage to the product incurred while it is in transit or is being shipped for repair. It is the buyer's responsibility to arrange for insurance, if the buyer so desires.

The Company does not warrant (a) any product, components or parts not manufactured by the Company, (b) defects caused by failure to provide a suitable installation environment for the Radio, (c) damage caused by disasters such as fire, flood, wind, and lightning, (e) damage caused by unauthorized attachments or modification, (f) damage during shipment, (g) any other abuse or misuse by the buyer, (h) that the Radio will be free from any claim for infringement of any patent, trademark, copyright or other proprietary right, including trade secrets.

THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND IF APPLICABLE, IMPLIED WARRANTIES UNDER ARTICLE 35 OF THE UNITED NATIONS CONVENTION ON CONTRACTS FOR THE INTERNATIONAL SALE OF GOODS.

IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING DIRECTLY OR INDIRECTLY OUT OF THE OWNERSHIP, USE OR OPERATION OF THE RADIO REGARDLESS OF WHETHER SUCH DAMAGES ARE PREDICATED OR BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT TORT, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF SAVINGS OR REVENUE, LOSS OF USE OF THE RADIO OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF ANY SUBSTITUTE EQUIPMENT, FACILITIES OR SERVICES, THE CLAIMS

1. The warranty against defects in ArWest adapter, antenna, battery, charger, or cable is 90 days.

Warranty Terms

OF THIRD PARTIES, INCLUDING CUSTOMERS AND INJURY TO PROPERTY. THIS LIMITATION DOES NOT APPLY TO CLAIMS FOR PERSONAL INJURY. SOME STATES DO NOT ALLOW LIMITS ON WARRANTIES, OR ON REMEDIES FOR BREACH IN CERTAIN TRANSACTIONS. IN SUCH STATES, THE LIMITS IN THIS PARAGRAPH AND THE PRECEDING PARAGRAPH MAY NOT APPLY.

No employee of the Company, or any other party, is authorized to make any warranty in addition to those made in this document. This warranty allocates the risks of product failure between the Company and the buyer. This allocation is recognized by both parties and is reflected in the price of the goods. The buyer acknowledges that it has read this warranty, understands it, and is bound by its terms. This limited warranty is governed by the laws of the State of California, without reference to its conflict of law provisions or the U.N. Convention on Contracts for the International Sale of Goods.

READER COMMENT FORM

We appreciate your comments and suggestions for improving this publication.

I use the following ArWest product _____
for _____

Please circle a response for each of the statements below:

1 = Strongly Agree 2 = Agree 3 = Neutral 4 = Disagree 5 = Strongly Disagree

The manual is well organized.	1	2	3	4	5
I can find the information I want.	1	2	3	4	5
The information in the manual is accurate.	1	2	3	4	5
I can easily understand the instructions.	1	2	3	4	5
The manual contains enough examples.	1	2	3	4	5
The examples are appropriate and helpful.	1	2	3	4	5
The layout and format are attractive and useful.	1	2	3	4	5
The illustrations are clear and helpful.	1	2	3	4	5
The manual is:	too long just right too short				

Please answer the following questions:

Which sections do you use the most? _____

What do you like best about the manual? _____

What do you like least about the manual? _____

Optional

Name _____

Company _____

Address _____

Telephone _____ Fax _____

Please mail to the ArWest local office listed on the back cover. All comments and suggestions become the property of ArWest Communications.



900 Rock Avenue, San Jose, CA 95131 USA

Tel: + 1(408) 770-1790

Fax: + 1(408) 770-1799

www.arwestcom.com

Copyright © ArWest Communications, 2012
All rights reserved. No unauthorized duplication.