



L-Band/Beacon

OEM Receiver User Manual

Version 2.1

Last Revised September 7, 2011

**All contents in this manual are copyrighted by ArWest Communications.
All rights reserved. The information contained herein may not be used, accessed, copied,
stored, displayed, sold, modified, published, or distributed, or otherwise reproduced without
express written consent from ArWest Communications.**

TABLE OF CONTENTS

Preface	5
Terms and Conditions	5
WEEE Directive	7
Technical Assistance	8
Return Material Authorization	8
Chapter 1. Product Features	9
1.1. Introduction	9
1.1.1. Media Access Control (MAC)	10
1.1.2. Management Tools	10
Chapter 2. General Description	11
2.1. Physical Interfaces	11
2.1.1. Serial Data Interface	11
2.1.2. Power Interface	11
2.1.3. Power Consumption	11
2.1.4. Antennas	12
Chapter 3. Command Line Interface	13
3.1. Command Line Interface Convention	14
3.1.1. Software Switching to Maintenance Mode	14
3.1.2. Hardware Switching to Maintenance Mode	15
3.1.3. Switching to Data Mode	15
3.2. Networking Commands	16
3.2.1. LINK	16
3.2.2. MAP	18
3.2.3. ANTENNA	18
3.3. Serial Interfacing Commands	19
3.3.1. PORT	19
3.4. Special Commands	19
3.4.1. ALARM	19
3.4.2. BOOT	20
3.4.3. HELP	20
3.4.4. SAVE	20

3.4.5. SLEEP	20
3.5. Diagnostics and Identification Commands	21
3.5.1. INFO	21
3.5.2. STATE	22
Appendix A. Technical Specifications	23
A.1. Technical Specifications	23
A.1.1. Radio Technical Specifications	23
A.1.2. L-Band Receiver Specification	23
A.1.3. Beacon Receiver Specification	24
A.1.4. General	25
A.1.5. Mechanical Properties For End-product	25
A.2. External Connectors	26
A.2.1. Antenna Connector	26
A.2.2. User Ports' Connector (Main connector J1)	27
Appendix B. Safety Warnings	29
B.1. General Warnings	29
Appendix C. Warranty Terms	31

PREFACE

Thank you for purchasing this product. The materials available in this Manual (the “Manual”) have been prepared by ArWest Communications (“ArWest Communications”) for owners of ArWest Communications products. It is designed to assist owners with the use of the L-Band Receiver and its use is subject to these terms and conditions (the “Terms and Conditions”).

Note: Please read these Terms and Conditions carefully.

Terms and Conditions

COPYRIGHT – All information contained in this Manual is the intellectual property of, and copyrighted material of ArWest Communications. All rights are reserved. You may not use, access, copy, store, display, create derivative works of, sell, modify, publish, distribute, or allow any third party access to, any graphics, content, information or data in this Manual without ArWest Communications’ express written consent and may only use such information for the care and operation of your L-Band Receiver. The information and data in this Manual are a valuable asset of ArWest Communications and are developed by the expenditure of considerable work, time and money, and are the result of original selection, coordination and arrangement by ArWest Communications.

TRADEMARKS – ArWest, ArWest Communications[®] are trademarks or registered trademarks of ArWest Communications. Windows[®] is a registered trademark of Microsoft Corporation. Product and company names mentioned herein may be trademarks of their respective owners.

DISCLAIMER OF WARRANTY – EXCEPT FOR ANY WARRANTIES IN THIS MANUAL OR A WARRANTY CARD ACCOMPANYING THE PRODUCT, THIS MANUAL AND THE L-Band Receiver ARE PROVIDED “AS-IS.” THERE ARE NO OTHER WARRANTIES. ArWest Communications DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE. ARWEST COMMUNICATIONS AND ITS DISTRIBUTORS SHALL NOT BE LIABLE FOR TECHNICAL OR EDITORIAL ERRORS OR OMISSIONS CONTAINED HEREIN; NOR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE FURNISHING, PERFORMANCE OR USE OF THIS MATERIAL OR THE L-Band Receiver. SUCH DISCLAIMED DAMAGES INCLUDE BUT ARE NOT LIMITED TO LOSS OF TIME, LOSS OR DESTRUCTION OF DATA, LOSS OF PROFIT, SAVINGS OR REVENUE, OR LOSS OF THE PRODUCT'S USE. IN ADDITION, ARWEST COMMUNICATIONS IS NOT RESPONSIBLE OR LIABLE FOR DAMAGES OR COSTS INCURRED IN CONNECTION WITH OBTAINING SUBSTITUTE PRODUCTS OR SOFTWARE, CLAIMS BY OTHERS, INCONVENIENCE, OR ANY OTHER COSTS. IN ANY EVENT, ARWEST COMMUNICATIONS SHALL HAVE NO LIABILITY FOR DAMAGES OR OTHERWISE TO YOU OR ANY OTHER PERSON OR ENTITY IN EXCESS OF THE PURCHASE PRICE FOR THE L-BAND RECEIVER.

Preface

Terms and Conditions

LICENSE AGREEMENT – Use of any computer programs or software supplied by ArWest Communications or downloaded from a ArWest Communications website (the “Software”) in connection with the L-Band Receiver constitutes acceptance of these Terms and Conditions in this Manual and an agreement to abide by these Terms and Conditions. The user is granted a personal, non-exclusive, non-transferable license to use such Software under the terms stated herein and in any case only with a single L-Band Receiver or single computer. You may not assign or transfer the Software or this license without the express written consent of ArWest Communications. This license is effective until terminated. You may terminate the license at any time by destroying the Software and Manual. ArWest Communications may terminate the license if you fail to comply with any of the Terms or Conditions. You agree to destroy the Software and manual upon termination of your use of the L-Band Receiver. All ownership, copyright and other intellectual property rights in and to the Software belong to ArWest Communications. If these license terms are not acceptable, return any unused software and manual.

CONFIDENTIALITY – This Manual, its contents and the Software (collectively, the “Confidential Information”) are the confidential and proprietary information of ArWest Communications. You agree to treat ArWest Communications' Confidential Information with a degree of care no less stringent than the degree of care you would use in safeguarding your own most valuable trade secrets. Nothing in this paragraph shall restrict you from disclosing Confidential Information to your employees as may be necessary or appropriate to operate or care for the L-Band Receiver. Such employees must also keep the Confidentiality Information confidential. In the event you become legally compelled to disclose any of the Confidential Information, you shall give ArWest Communications immediate notice so that it may seek a protective order or other appropriate remedy.

WEBSITE; OTHER STATEMENTS – No statement contained at the ArWest Communications website (or any other website) or in any other advertisements or ArWest Communications literature or made by an employee or independent contractor of ArWest Communications modifies these Terms and Conditions (including the Software license, warranty and limitation of liability).

SAFETY – Improper use of the L-Band Receiver can lead to injury to persons or property and/or malfunction of the product. The L-Band Receiver should only be repaired by authorized ArWest Communications warranty service centers. Users should review and heed the safety warnings.

MISCELLANEOUS – The above Terms and Conditions may be amended, modified, superseded, or canceled, at any time by ArWest Communications. The above Terms and Conditions will be governed by, and construed in accordance with, the laws of the State of California, without reference to conflict of laws.

WEEE Directive

The following information is for EU-member states only:

The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the take-back and recycling of this product, please contact your supplier where you purchased the product or consult.



Preface

Technical Assistance

Technical Assistance

If you have a problem and cannot find the information you need in the product documentation, contact your local dealer. Alternatively, request technical support using the ArWest Communications World Wide Web site at: www.arwestcom.com

Return Material Authorization

Initially, the customer contacts support to report a problem. Please refer to support: support@arwestcom.com

If support determines the problem cannot be resolved over e-mail/internet, it will authorize the return of the unit for repair or replacement, depending on the nature of the problem.

PRODUCT FEATURES

1.1. Introduction

L-Band Receiver/Beacon OEM Receiver comprises two radio sections: L-Band receiver (1518 MHz to 1559 MHz) and Marine Radiobeacon receiver (283.5 to 325 kHz).

L-Band receiver complies with INMARSAT SDM Technical Specification for narrow band point-to-multipoint receivers as defined in INMARSAT-A Mobile Earth Station Technical Bulletin, SESTB 28A, August 1993. L-Band receiver is designed for multiple applications including particularly geostationary satellite communication networks satellite services.

Potential applications are differential GPS correction parameter distribution, financial data distribution, news, weather and sport information distribution, store and forward audio distribution, facsimile and image distribution, control of remote equipment.

Marine Radiobeacon receiver (283.5 to 325 kHz) or Beacon receiver complies with Broadcast Standard for the USCG DGPS Navigation Service COMDTINST M16577.1. Beacon receiver is designed to receive pseudorange corrections transmitting by Radiobeacon stations. Maritime Radiobeacon DGNSS systems according to RTCM SC-104 version 2.3 are usually capable of broadcasting the following RTCM messages: 1, 2, 3, 5, 6, 7, 9, 15 (seldom), and 16. Radiobeacons are widely used throughout the world.

GNSS Radiobeacon transmissions meet stringent integrity and reliability requirements mandated by the International Association of Lighthouse Authorities.




Figure 1-1. L-Band-Beacon Receiver

Product Features

Introduction

Media Access Control (MAC)

The delivered product is a wireless system, which includes:

- L-Band/Beacon Receiver – L-Band/Beacon receiver OEM board;
- AWLaunch – Windows based Unit Configuration and Maintenance Software Application running on a IBM PC compatible computer and connecting to the device over RS-232 interface or USB-to-Serial adapter.

The setting can be done through the built-in Command Line interface (CLI), or through the configuration and maintenance application software running either on PC – AWLaunch.

The diagnostic feature of the L-Band-Beacon Receiver system provides the information to monitor and maintain user's communications link.

The product is designed for maximum performance and reliability even in the hardest environments. Plug and play at its best, robust, withstanding the most adverse of conditions.

1.1.1. Media Access Control (MAC)

The following Media Access protocols are available for L-Band-Beacon Receiver modem:

1. L-Band protocols
2. Beacon protocols
3. Sleep mode¹ is an investment provided by MAC sub-layer that provides additional power saving. The wakeup from Sleep mode is user selectable either by an internal real-time clock, or by an external controller through the data interface control lines (RTS or DTR), or by SLEEP input line (CMOS/TTL compatible input lines).

1.1.2. Management Tools

The built-in management tools along with AWLaunch (configuration and monitoring software application) will provide the following benefits:

1. Easy user's interface for system configuration and monitoring using well developed CLI or intuitive GUI.
2. An ability to monitor status, alarms and radio performance through the intuitive GUI.
3. Software upgrades and improvements can be downloaded from AWLaunch to the units connected with PC/PDA.

1. This feature is not supported in the current firmware version, it will be supported in the future.

GENERAL DESCRIPTION

2.1. Physical Interfaces

2.1.1. Serial Data Interface

The serial asynchronous interface allows connection to external serial devices. It is shared between user data and unit's command/status information.

2.1.2. Power Interface

The power interface allows connection to an unregulated DC power source. The DC power source (third-party or user supplied) must provide DC power of $4.2V \pm 5\%$ DC.

2.1.3. Power Consumption

Power consumption of the L-Band receiver at receiving mode is 1400 mW (refer to Table 2-1 for details).

Table 2-1. Power Consumption

Operating Mode / Description	Consumption
Maximum for Rx Full Operation Mode	1400 mW
Sleep Mode	300 mW
Standby Mode, ordered by SLEEP input pin	500 μ W

General Description

Physical Interfaces

Antennas

2.1.4. Antennas

The L-Band/Beacon receiver should be used with any 1518-1559 MHz and/or 283.5 - 325 kHz antenna with following parameters:

- LNA Gain P30 dB
- LNA Noise Figure 1.5 dB

COMMAND LINE INTERFACE

The built-in user-friendly Command Line Interface (CLI) allows user to perform a full configuration of the unit and read the statistics and alarm status. It is the most powerful tool to configure the unit. It makes changes to all possible settings that system will not be able to determine automatically.

The CLI commands allow user to configure and reconfigure the unit's settings. The user configuration parameters that could be changed through the CLI are:

- Data Port Settings
 - Baud Rate
 - Flow control (None or RTS/CTS)
- Alarm Settings¹
- Radio Operation Modes
- Sleep modes²
 - On/Off
 - Activate by internal real-time clock
 - Activate through RTS/CTS lines
 - Activate by external sense lines
 - Activate by any combination of the parameters mentioned before

Note: The unit's configuration that is set or modified through the CLI will be lost after unit's reboot, unless the saving operation is used to store a new setting in the unit's configuration file.

The CLI commands also provide filing operations, which include:

- Downloading
 - Unit's Configuration files
 - Software Images
- Uploading Unit's Configuration files
- Saving into the configuration files the configuration parameters modified through the CLI.

1. The Alarm is not supported currently. It will be supported in the future firmware version.

2. The Sleep is not supported currently. It will be supported in the future firmware version.

Command Line Interface

Command Line Interface Convention
Software Switching to Maintenance Mode

3.1. Command Line Interface Convention

The following convention is implemented in L-Band Receiver Command Line Interface (CLI):

- The Carriage Return/Line Feed (CR/LF, 0x0D/0x0A) is a command delimiter.
- The Carriage Return/Line Feed (CR/LF, 0x0D/0x0A) is a reply delimiter followed by the “CLI>” prompt if Echo option is On.
- The Carriage Return/Line Feed (CR/LF, 0x0D/0x0A) is a reply delimiter if Echo option is Off (default option).
- The 2-digit number followed by “@” in the unit’s reply indicates the error code (refer to Table 3-1 for description).
- A successfully performed command is replied by @00 code for both Echo ON and OFF modes.
- A command with the certain [*Parameter Name*] and blank [*Parameter List*] displays the current settings for a given parameter.
- To set the mode ordered by CLI commands as permanent User Setting (the setting automatically selected for the boot-up unit) the SAVE command must be asserted.
- [/?] orders to show the help information for the given command.
- Commands are not key sensitive; small, none capital characters can be used to enter CLI commands.

Table 3-1. Command Line Interface Error Codes

Error Code	Short Description
0x01	Command Syntax Error. A command followed by “/?” displays a command usage.
0x02	The parameter has a format error. A command with the certain [<i>Parameter Name</i>] followed by “/?” displays the format and range of the variable.
0x03	The parameter is out of allowed range. A command with the certain [<i>Parameter Name</i>] followed by “/?” displays the format and range of the variable.
0x04	The command is not valid for specific radio model. To display the list of available commands, the HELP command must be used (see “Software Switching to Maintenance Mode”).
0x05	Unspecified Error

3.1.1. Software Switching to Maintenance Mode

To switch to Maintenance mode the special byte-sequences with special meanings are used:

- Escape-Sequence: “+++” with 20 ms guard time before and after the command characters
- Escape-Acknowledge: “@00<CR><LF>” 20 ms toggling on CTS control line needed to acknowledge switching from Data to Maintenance mode and vice versa. In Maintenance mode, the unit’s serial port must keep CTS line always active.

Happy Flow

1. In data-mode the unit starts looking for the Escape-sequence if there is no data from DTE for more than 20 ms (Start Guard Time).
2. If the unit detects the Escape-Sequence:
 - The Receiver immediately stops forwarding to DTE the data received over the air and buffers it instead.
3. The radio unit waits for 20 ms and then sends Escape-Acknowledge to DTE if there is no data from DTE during 20 ms of Stop Guard Time.
4. The unit goes to Maintenance mode and discards Escape-Sequence from input buffer. The modem is immediately ready to receive commands. At the same time it continues buffering the data received over the air since step 2.

3.1.2. Hardware Switching to Maintenance Mode

As alternative to Software Switching, the switching through the MP/DP control line can be used (this control line can be also used as Data Terminal Ready, DTR). To set Maintenance mode, the DTE must assert DTR signal active (0v level). By falling edge of DTR signal the unit goes to Maintenance mode and then sends Escape-Acknowledge to DTE („@00<CR><LF>“).

20 ms toggling on CTS control line followed by Escape-Acknowledge response is needed to acknowledge switching from Data to Maintenance mode and vice versa. In Maintenance Mode, the unit's serial port must keep Clear to Send (CTS) line always active (see also “Special Commands” on page 19).

Note: The powered up radio modem always goes to data mode.

3.1.3. Switching to Data Mode

- DTE sends the CLI command „DATAMODE<CR><LF>“ to the unit.
- Unit immediately goes to data mode without Escape Acknowledge.
- If no valid CLI commands received from DTE within 1 minute, the unit will automatically switch back to data-mode.

Note: The data received over the air could be lost due to Rx buffer overflow if the unit stays in Maintenance mode longer than 15 seconds.

Command Line Interface

Networking Commands

LINK

3.2. Networking Commands

3.2.1. LINK

The LINK command is responsible for configuring radio's operation mode.

LINK [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List		
SAR	Sets/gets the active receiver e.g. 0 - L-Band receiver is selected; 1 - Beacon receiver is selected. After active receiver is selected the corresponding receiver starts demodulation process. The Wireless LINK and Statistics commands (LINK, MAP, STATE) correspond to the selected active receiver.		
CHAN	Sets/gets the current frequency channel number of the active receiver. Up to 32 channels are available in the channel map (example LINK CHAN 24). Refer to MAP command about creating and modifying the active receiver channel map.		
SIGTYPE	Sets/gets the signal type of the active receiver.		
	Parameter	L-Band	Beacon
	1	4800 bps	100 bps
	2	2400 bps	200 bps
	3	1200 bps	50 bps
	4	600 bps	N/A
5	300 bps	N/A	
SCRAM	Sets/gets the 16 bit scrambling initial seed in hex format. By default this value is set 0x5C08. The SCRAM parameter is available for L-Band receiver only. (Example - "LINK SCRAM 5C08")		
MSG	Sets/gets the output data format (raw data or special unsolicited messages, refer to Unsolicited output messages section for message types description): 0 - Raw data 1 - Activates Frame messages; 2 - Activates Data messages; 3 - Activates Frame and Data messages; 4 - Activates Status messages; 5 - Activates Status and Frame messages; 6 - Activates Status and Data messages; 7 - Activates all 3 (Frame, Data and Status) messages. The MSG parameter is available for L-Band receiver only. (example LINK MSG 3)		
RSID	Gets the received service identifier within the frame (in hex format). The RSID parameter is available for L-Band receiver only.		
UW	Sets/gets the 8 byte length Unique Word for 1-5 signal types (hex format is used). This parameter is used by L-Band receiver in frame synchronization process for 1-5 signal types. The UW parameter is available for L-Band receiver only. (Example "LINK UW E15AE893E15AE893")		
UWERRT	Sets/gets the error bits numbers threshold. This threshold is used in frame synchronization process - if the number of error bits in received unique word is greater than this threshold, the corresponding frame is discarded. The default value of this parameter is set to 12. The UWERRT parameter is used for L-Band receiver only.		

Unsolicited output messages

The “Status”, “Frame” and “Data” messages are available to be activated for L-Band receiver (refer to LINK MSG command for output data format configuration). Here is the description and structure of each type of message.

Message Type	Description
Status	<p>The L-Band demodulator generates an unsolicited status report once every second (± 200ms) containing the following fields:</p> <ul style="list-style-type: none"> • Header byte - 0x55; • Message type byte - 0x02; • Message payload length in 1 byte; • The signal type that is attempting to receive; • The tuned frequency offset relative to set frequency in Hz represented in 4 bytes (high byte first); • The synchronization status in 1 byte (e.g. 1 - synchronized, 0 - unsynchronized); • The RSSI level in 2 bytes (high byte first); • The estimated C/N0 of the received signal in dBHz represented in 1 byte. When not synchronized, this value is set to zero.
Frame	<p>When synchronized, the L-Band demodulator generates an unsolicited frame information report once every frame period containing the following fields:</p> <ul style="list-style-type: none"> • Header byte - 0x55; • Message type byte - 0x03; • Message payload length in 1 byte; • The number of hard decision bit errors encountered in the UW represented in 1 byte; • The service identifier received within the frame in 2 bytes (high byte first); • The spare byte received within the frame.
Data	<p>When receiving data from the satellite, the L-Band demodulator generates unsolicited messages containing the received data. Each data message contains an integer number of bytes and contains no more than 200 milliseconds worth of received data. The following is the message structure:</p> <ul style="list-style-type: none"> • Header byte - 0x55; • Message type byte - 0x01; • Message payload length byte; • Zero or more bytes of L-Band frame payload.

Command Line Interface

Networking Commands

MAP

3.2.2. MAP

The MAP command is used to create, modify and save the channel map of the active receiver. Refer to LINK SAR command about active receiver setting.

MAP [*C*<Parameter>][*F*<Parameter>][*SAVE*]

Parameter Name	Description
C	Channel number of active receiver (1- 32).
F	Carrier frequency of active receiver in Hz.
SAVE	Saves the channel map.

The MAP command without parameters displays the channel map of the active receiver.:

Example: MAP c1 F1535000000 - sets the 1535 MHz frequency to channel1 of active receiver;

MAP SAVE - saves the channel map.



3.2.3. ANTENNA

The ANTENNA command is used to set the antenna power state and to select the RF connector which should be used for Beacon receiver. Refer to External connectors section for their description.

ANTENNA [*Parameter Name*] [*Parameters List*] [*/?*]

Parameter Name	Parameter List
POWER	0 - Switches off the antenna power on the J300/J302 connectors. 1 - Switches on the antenna power on J300/J302 connectors.
BEACON	0 - Selects the J302 connector for Beacon receiver. 1 - Selects the J300 connector for Beacon receiver.

The ANTENNA command without parameter name indicates all values.

3.3. Serial Interfacing Commands

3.3.1. PORT

The PORT is an object that responsible for data port interface configurations like Bit Rate, Flow Control, etc.

Port rate and Port flow commands are available. The data bits is set to 8, stop bits to 1 and parity to None in the firmware As an example you can write PORT RATE 9 which selects 115200 baud rate and PORT FLOW 2 which enables hardware flow control.

PORT [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
RATE	1 - 1200 baud rate 2 - 2400 baud rate 3 - 4800 baud rate 4 - 9600 baud rate 5 - 14400 baud rate 6 - 19200 baud rate 7 - 38400 baud rate 8 - 57600 baud rate 9 - 115200 baud rate
FLOW	0 – No flow control 2 – Hardware flow control is on

3.4. Special Commands

3.4.1. ALARM¹

The ALARM command is intended to set up the alarm indication mode and alarm control lines' behavior.

ALARM [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
TTL1	0 – TTL_OUT1 = logic “1” 1 – TTL_OUT1 = TTL_IN, received from remote unit (default settings)
TTL2	0 – TTL_OUT2 = logic “1” 1 – TTL_OUT2 = TTL_IN2, received from remote unit (default settings) 2 – TTL_OUT2 = SYNC Loss 3 – TTL_OUT2 = BER > BERTH or SYNC Loss
BERTH	1– BER Threshold $>10^{-3}$ (default threshold level for BER) 2 – BER Threshold $BER >10^{-2}$

Note: The BERTH 1 / 2 is optional for TTL2 = 3 condition, otherwise the BERT alarm is off

1. Not supported in the current firmware version

Command Line Interface

Special Commands

BOOT

3.4.2. BOOT

The BOOT command is intended to reboot the unit using selected user settings. Two options are available, to use the default user settings defined by dealer or to use the settings defined by end-user. The BOOT command with no parameters selects the user settings defined by the prior “parameterized” BOOT commands.

3.4.3. HELP

The HELP command types the list of all available commands:

```
HELP      - Display this usage
BOOT      - Reboot the unit
LINK      - RF Link Operation Mode
PORT      - Data Port Configuration
ALARM     - Alarm Indication and Alarm Control Configuration
SLEEP     - Sleep Mode Configuration
STATE     - Display Status and Statistics
SAVE      - Save Current Configuration into Configuration File
INFO      - Display Product ID along with Hardware/Software Versions
DATAMODE  - Exit Maintenance Mode
[COMMAND] /? - Display Command Usage
```

3.4.4. SAVE

The SAVE command is intended to store the unit’s currently used configuration into the User Configuration file. The configuration stored in the User Configuration file is activated by automatically after unit’s reboot.

3.4.5. SLEEP¹

The SLEEP command determines the sleep mode parameters. The sleeping L-Band Receiver can be activated by real-time CLK, DTR/RTS lines, and command received through TTL inputs. The user can select one, two, or all three conditions.

SLEEP [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
CLK	0 – Do not activate by internal real-time clock (1 – 255) – Activate by internal real-time clock after 100 to 25500 msec of sleeping
HW	0 – Do not activate through DTR/RTS lines 1 – Activate through DTR/RTS lines

1. Not supported in the current firmware version

Parameter Name	Parameter List
TTL	0 – Do not activate by external sense lines 1 – Activate by external sense lines
GTS	0 – Disable Sleep mode (default) (1 – 255) – Go to sleep mode if there is no activity in 10 to 2550 msec Example: SLEEP GTS 100 (go to sleep if there is no activity in 1000 ms);

3.5. Diagnostics and Identification Commands

3.5.1. INFO

The INFO command is used to retrieve the Radio ID along with its Hardware version, the loaded real-time software version/revision and BootLoader’s version/revision.

INFO [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
ID	Retrieves the device identifier
SN	Retrieves the serial number of the modem (unique for each unit)
HW	Retrieves the version string of the hardware 1.0 – hardware version in numeric “Major.Minor” format
SW	Retrieves the version string of the current firmware Ver. 1.0 Rev. A – displays software’s version in numeric “Major.Minor” format and revision in numeric format (range from 01 to 99) for engineering releases and alphabetic format (A to Z) for manufacturing releases
BL	Retrieves the version string of the BootLoader Ver. 1.0 Rev. A – displays BootLoader’s version in numeric “Major.Minor”format and revision in numeric format (range from 01 to 99) for engineering releases and alphabetic format (A to Z) for manufacturing releases

The INFO command without Parameter Name indicates all values:

```
L-Band Receiver
Product ID = 36
S/N = 000000 020303
Hardware = Ver 3.1
Software = Ver. 1.8 Rev 04
BootLoader = Ver. 3.0 Rev. 02
```

Command Line Interface

Diagnostics and Identification Commands

STATE

3.5.2. STATE

The STATE command is used to check the wireless link state of the currently selected active receiver. Refer to LINK SAR command for active receiver setting.

STATE [*Parameter Name*] [*Parameters List*] [/?]

Parameter Name	Parameter List
RSSI	Retrieves the calculated received signal level of the active receiver in dBm.
SYNC	Indicates the synchronization status of active receiver (0 - no synchronization, 1 - synchronization established)
BER	Retrieves the mean Bit error rate calculated on the last received 16 frames (BER parameter is used for L-Band receiver only)
FREQ	Retrieves the current channel frequency of active receiver in Hz
FREQOFFSET	Retrieves the tuned frequency offset of active receiver relative to the set frequency after the synchronization established.
SYMRATE	Retrieves the current symbol rate of active receiver.
CNR	Retrieves the estimated carrier to noise ratio of the active receiver within 16 frames after synchronization established (currently the CNR parameter is used for L-Band receiver only).
EBNO	Retrieves the estimated Eb/No of the active receiver within 16 frames after synchronization established (currently the EBNO parameter is used for L-Band receiver only).
TEMP	-30°C - +100°C retrieves the temperature inside enclosure

TECHNICAL SPECIFICATIONS

A.1. Technical Specifications

A.1.1. Radio Technical Specifications

Table A-1. Radio Specifications

Component	Details
Frequency Range	1518 - 1559 MHz
Frequency Offset	± 3kHz (~2ppm)
Channel Spacing	5 kHz
User Data Rates	300, 600, 1200, 2400, 4800 bps
Service Identifier	User defined
Scrambler Vector	User defined
Tuning Mode	manual/automatically
Sensitivity	-120 dBm for <10 ⁻³ BER
Dynamic Range	80 dB
Adjacent Channel Rejection	60 dB
Start Time	<1 min
Output Data Format	Raw data or special unsolicited messages. Refer to LINK MSG command for output data format configuration.

A.1.2. L-Band Receiver Specification

Table A-2. L-Band Receiver Specification

Component	Details
Input Impedance	50 Ohms
Max Overload Input Signal of Normal Power Level	+ 0 dBm
Satellite Symbol Ratio	609.524, 1219.047, 2438.095, 4576.190, 9752.380 symbol/second
Assigned Bandwidth	2.5, 5.0, 7.5, 15.0 kHz
Modulation Type filtered	BPSK
Filtering	40% square-root raised cosine

Technical Specifications

Technical Specifications
Beacon Receiver Specification

Component	Details
Channel Coding	Rate 1/2 convolutional Constant K=7
Decoding Algorithm	Viterbi
Channel Scrambling	V.35 prior to FEC as defined in Inmarsat-M (Scrambler vector related to Service identifier)
Frame Length	8192 symbols
Unique Word Length	2 x 32 bits (not encoded or scrambled)
Spare Byte	8 bits (encoded but not scrambled)
E_b/N_0 for BER = 10^{-5}	5.5 dB

A.1.3. Beacon Receiver Specification

Figure A-1. Beacon Receiver Specification

Component	Details
Frequency Range	283.5 - 325 kHz
Channel Spacing	500 Hz
Bit Rates	50, 100, 200 bps (manual or Auto selection)
Channels	2-channel, parallel operating
Operation Mode	manual/automatic
Adjacent Channel Rejection	65 dB \pm 1 dB @ for \pm 400 Hz
Cold Start Time	<1 min
Warm Start Time	<2 seconds
Modulation	Minimum Shift Keying (MSK)
Sensitivity	1.5 m V/m for 6 dB SNR (200 bps)
Dynamic Range	100 dB
Frequency Offset	\pm 0.5 Hz (~ 1.5 ppm)
Correction Output Protocol	RTCM SC-104

Technical Specifications


External Connectors

Antenna Connector

A.2. External Connectors

A.2.1. Antenna Connector

J300 Beacon/GNSS RF Input Connector / J301 LNA Output to GNSS Board Connector/ J302 L-band/ Beacon/GNSS RF Input Connector: MMCX RIGHT ANGLE PCB JACK, AMPHENOL P/N 908-24100.



Through the central pin of the connector J300/J302 the power is being supplied to the antenna LNA. The internal power supply provides 4.2 V DC and max 0.2 A. If an antenna needs another voltage, the external power supply should be connected to the pin 10 of main connector J1. If jumper R117 is installed, the antenna supply voltage through the central pin of J300/J302 is equal to the external voltage applied to this pin. The external voltage should be in range +5 ... +15 VDC and the current is less than 0.2 A.

A.2.2. User Ports' Connector (Main connector J1)

The user ports' connector is used to provide connection with an external DTE or with the PC running AWLaunch management software applications.

L-Band Receiver in PCB mounted enclosure uses 16-Lead Header Connector, ECS Corp. P/N 9616-D1-01-03.

PIN #	Signal Designator	Signal name	Description	I/O	Comments
1	GND	GND	Ground	-	Signal and Chassis Ground
2	DSP UART 1	TXD	Transmit Data	TTL Input	Serial Data Input
3	DSP UART 2	RXD	Receive Data	TTL Output	Output for received serial data
4	DPORT5	DTR or DP/MP	Data Terminal Ready	TTL Input	Control line can be used as a backup method for entering Command mode: (0V) – Maintenance Mode; (3.3V) – Data Mode An internal 100K pull-up enables Data Mode if this signal is left unconnected. Maintenance Mode is also accessible by transmitting an escape sequence.
5	DPORT1	CTS	Clear to Send	TTL Output	Used to control data flow from the user to the radio: (0V) –Data buffer not full, (3.3V) – Data buffer full
6	TTLI1	SLEEP	Sleeps/wakes radio Receive only	TTL Input	In sleep mode, all radio functions are disabled consuming less than 50iA. An internal 10K pull-down wakes up the radio if this signal is left unconnected. At wake up, any user programmed configuration settings are refreshed from flash memory, clearing any temporary settings that may have been set: (3.3V) – Sleep Radio; (0V) – Wake Radio As an option could be used as TTL Input Line 1
7	DPORT3	DCD	Data Carrier Detect	TTL Output	Used by remotes to indicate that the remote has successfully acquired the signal from base station: (0V) – Carrier detected (synchronized); (3.3V) – No carrier detected (not synchronized)
8	DPORT4	RTS	Request to Send	TTL Input	Gates the flow of receive data from the radio to the user on or off. An internal 10K pull-down enables data receive if this signal is left unconnected. In normal operation, this signal should be asserted: (0V) – Receive data (Rx) enabled (3.3V) – Receive data (Rx) disabled
9	DPORT2	DSR	Data Set Ready	TTL Output	Used to control transmit flow from the user to the radio: (0V) – Receive buffer has data to transfer; (3.3V) – Receive buffer is empty

Technical Specifications

External Connectors

User Ports' Connector (Main connector J1)

PIN #	Signal Designator	Signal name	Description	I/O	Comments
10	ANT_DC	ANT_DC	External Power for Antenna LNA	Power Input	External Power for Antenna LNA +5...+15 VDC
11	TTLO1	TTLOUT1	TTL Output Line 1	TTL Output	Reserve line
12	TTLO2	TTLOUT2	TTL Output Line 2	TTL Output	Reserve line
13	GND	GND	Ground	-	Signal and Chassis Ground
14	TTLI2	TTLIN	TTL Input line	TTL Input	An internal 100K pull-up resistor is applied.
15	VCC42	PWR	Power Supply	External	Regulated positive 4.2V DC from ext. Power Supply.
16	VCC42	PWR	Power Supply	External	Regulated positive 4.2V DC from ext. Power Supply.

SAFETY WARNINGS

Read these instructions.

- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Clean only with a damp cloth.
- Do not block any of the ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, or has been dropped.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, shall be placed on the apparatus.

B.1. General Warnings

This product should never be used:

- Without the user thoroughly understanding operator's manual.
- After disabling safety systems or altering the product.
- With unauthorized accessories.
- Contrary to applicable laws, rules, and regulations.

DANGER: THE L-BAND/BEACON RECEIVER SHOULD NEVER BE USED IN DANGEROUS ENVIRONMENTS.

Safety Warnings

General Warnings

WARRANTY TERMS

ArWest Communications Corp., Inc. (“Company”) warrants, to the end-user only, that the Narrow Band Radio Modems (“Radios”) purchased (a) conforms to the Company’s published specifications for the model purchased, and (b) is free from defects in material or workmanship. The duration of this warranty is twelve (12) months¹ from date of purchase and any claim for breach of warranty must be brought to the Company’s attention within such twelve (12) month period and the Receiver must be returned for action on any such claim within twelve (12) months from the date of purchase. Within a reasonable period of time after a claim, the Company will correct any failure of the Radio to conform to specifications or any defect in materials or workmanship, or replace the Radio, or, at its option, provide a full refund of the purchase price. A repaired or replaced product is warranted for 90 days from the date of return shipment to the buyer, or for the balance of the original warranty period, whichever is longer. These remedies are the buyer’s exclusive remedies for breach of warranty.

To obtain warranty service, the buyer must return the Radio, postage-paid, with proof of the date of original purchase and the buyer's return address to the Company or an authorized service center. The Company will not be responsible for any loss or damage to the product incurred while it is in transit or is being shipped for repair. It is the buyer's responsibility to arrange for insurance, if the buyer so desires.

The Company does not warrant (a) any product, components or parts not manufactured by the Company, (b) defects caused by failure to provide a suitable installation environment for the Radio, (c) damage caused by disasters such as fire, flood, wind, and lightning, (e) damage caused by unauthorized attachments or modification, (f) damage during shipment, (g) any other abuse or misuse by the buyer, (h) that the Radio will be free from any claim for infringement of any patent, trademark, copyright or other proprietary right, including trade secrets.

THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND IF APPLICABLE, IMPLIED WARRANTIES UNDER ARTICLE 35 OF THE UNITED NATIONS CONVENTION ON CONTRACTS FOR THE INTERNATIONAL SALE OF GOODS.

IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING DIRECTLY OR INDIRECTLY OUT OF THE OWNERSHIP, USE OR OPERATION OF THE RADIO REGARDLESS OF WHETHER SUCH DAMAGES ARE PREDICATED OR BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT TORT, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF SAVINGS OR REVENUE, LOSS OF USE OF THE RADIO OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF ANY SUBSTITUTE EQUIPMENT, FACILITIES OR SERVICES, THE CLAIMS

1. The warranty against defects in ArWest adapter, antenna, battery, charger, or cable is 90 days.

Warranty Terms

OF THIRD PARTIES, INCLUDING CUSTOMERS AND INJURY TO PROPERTY. THIS LIMITATION DOES NOT APPLY TO CLAIMS FOR PERSONAL INJURY. SOME STATES DO NOT ALLOW LIMITS ON WARRANTIES, OR ON REMEDIES FOR BREACH IN CERTAIN TRANSACTIONS. IN SUCH STATES, THE LIMITS IN THIS PARAGRAPH AND THE PRECEDING PARAGRAPH MAY NOT APPLY.

No employee of the Company, or any other party, is authorized to make any warranty in addition to those made in this document. This warranty allocates the risks of product failure between the Company and the buyer. This allocation is recognized by both parties and is reflected in the price of the goods. The buyer acknowledges that it has read this warranty, understands it, and is bound by its terms. This limited warranty is governed by the laws of the State of California, without reference to its conflict of law provisions or the U.N. Convention on Contracts for the International Sale of Goods.

READER COMMENT FORM

We appreciate your comments and suggestions for improving this publication.

I use the following ArWest product _____
for _____

Please circle a response for each of the statements below:

1 = Strongly Agree 2 = Agree 3 = Neutral 4 = Disagree 5 = Strongly Disagree

The manual is well organized.	1	2	3	4	5
I can find the information I want.	1	2	3	4	5
The information in the manual is accurate.	1	2	3	4	5
I can easily understand the instructions.	1	2	3	4	5
The manual contains enough examples.	1	2	3	4	5
The examples are appropriate and helpful.	1	2	3	4	5
The layout and format are attractive and useful.	1	2	3	4	5
The illustrations are clear and helpful.	1	2	3	4	5
The manual is:	too long just right too short				

Please answer the following questions:

Which sections do you use the most? _____

What do you like best about the manual? _____

What do you like least about the manual? _____

Optional

Name _____

Company _____

Address _____

Telephone _____ Fax _____

Please mail to the ArWest local office listed on the back cover. All comments and suggestions become the property of ArWest Communications.



900 Rock Avenue, San Jose, CA 95131 USA

Tel: + 1(408) 770-1790

Fax: + 1(408) 770-1799

www.arwestcom.com

Copyright © ArWest Communications, 2011
All rights reserved. No unauthorized duplication.