



# **BT4EX8M Evaluation Kit**

## **Application Notes**

**Version 1.0**

**Last Revised September 28, 2010**

**All contents in this manual are copyrighted by ArWest Communications.  
All rights reserved. The information contained herein may not be used, accessed, copied,  
stored, displayed, sold, modified, published, or distributed, or otherwise reproduced without  
express written consent from ArWest Communications.**

# TABLE OF CONTENTS

<b>Preface</b> .....	<b>3</b>
Terms and Conditions .....	3
Regulatory Information .....	4
WEEE Directive .....	5
Technical Assistance .....	5
Return Material Authorization .....	5
<b>Chapter 1. Introduction</b> .....	<b>7</b>
<b>Chapter 2. Connection</b> .....	<b>9</b>
2.1. Powering the Evaluation Board .....	9
2.2. Bluetooth Antenna Connection .....	9
2.3. USB Connection .....	10
2.4. Serial RS-232 Connection .....	10
2.5. Parallel Connection .....	11
2.6. Test Pins Connection .....	12
2.6.1. PIO (J3) .....	12
2.6.2. AIO (J6) .....	12
2.6.3. PCM (J7) .....	13
2.6.4. RESET (J8) .....	13
2.6.5. 1V8 (J9) .....	13
<b>Appendix A. Warranty Terms</b> .....	<b>15</b>
<b>Appendix B. Safety Warnings</b> .....	<b>17</b>
B.1. General Warnings .....	17

# PREFACE

Thank you for purchasing this product. The materials available in these Application Notes (the “Application Notes”) have been prepared by ArWest Corporation (“ArWest”) for owners of ArWest products. It is designed to assist owners with the use of BT4EX8M Evaluation Kit and its use is subject to these terms and conditions (the “Terms and Conditions”).

**Note:** Please read these Terms and Conditions carefully.

## Terms and Conditions

**COPYRIGHT** – All information contained in these Application Notes is the intellectual property of, and copyrighted material of ArWest. All rights are reserved. You may not use, access, copy, store, display, create derivative works of, sell, modify, publish, distribute, or allow any third party access to, any graphics, content, information or data in these Application Notes without ArWest’ express written consent and may only use such information for the care and operation of your BT4EX8M Evaluation Kit. The information and data in these Application Notes are a valuable asset of ArWest and are developed by the expenditure of considerable work, time and money, and are the result of original selection, coordination and arrangement by ArWest.

**TRADEMARKS** – BT4EX8M Evaluation Kit<sup>™</sup>, ArWest<sup>®</sup> are trademarks or registered trademarks of ArWest. Windows<sup>®</sup> is a registered trademark of Microsoft Corporation; Product and company names mentioned herein may be trademarks of their respective owners.

**DISCLAIMER OF WARRANTY** – EXCEPT FOR ANY WARRANTIES IN THESE APPLICATION NOTES OR A WARRANTY CARD ACCOMPANYING THE PRODUCT, THESE APPLICATION NOTES AND THE BT4EX8M EVALUATION KIT ARE PROVIDED “AS-IS.” THERE ARE NO OTHER WARRANTIES. ARWEST DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE. ARWEST AND ITS DISTRIBUTORS SHALL NOT BE LIABLE FOR TECHNICAL OR EDITORIAL ERRORS OR OMISSIONS CONTAINED HEREIN; NOR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE FURNISHING, PERFORMANCE OR USE OF THESE MATERIAL OR THE BT4EX8M OEM BOARDS. SUCH DISCLAIMED DAMAGES INCLUDE BUT ARE NOT LIMITED TO LOSS OF TIME, LOSS OR DESTRUCTION OF DATA, LOSS OF PROFIT, SAVINGS OR REVENUE, OR LOSS OF THE PRODUCT’S USE. IN ADDITION, ARWEST IS NOT RESPONSIBLE OR LIABLE FOR DAMAGES OR COSTS INCURRED IN CONNECTION WITH OBTAINING SUBSTITUTE PRODUCTS OR SOFTWARE, CLAIMS BY OTHERS, INCONVENIENCE, OR ANY OTHER COSTS. IN ANY EVENT, ARWEST SHALL HAVE NO LIABILITY FOR DAMAGES OR OTHERWISE TO YOU OR ANY OTHER PERSON OR ENTITY IN EXCESS OF THE PURCHASE PRICE FOR THE BT4EX8M Evaluation KIT.

**LICENSE AGREEMENT** – Use of any computer programs or software supplied by ArWest or downloaded from a ArWest website (the “Software”) in connection with the BT4EX8M Evaluation Kit constitutes acceptance of these Terms and Conditions in these Application Notes and an agreement to abide by these Terms and Conditions. The user is granted a personal, non-exclusive, non-transferable license to use such Software under the terms stated herein and in any case only with a single BT4EX8M Evaluation Kit or single computer. You may not assign or transfer the Software or this license without the express written consent of ArWest. This license is effective until terminated. You may

## Preface

### Regulatory Information

terminate the license at any time by destroying the Software and Application Notes. ArWest may terminate the license if you fail to comply with any of the Terms or Conditions. You agree to destroy the Software and application notes upon termination of your use of the BT4EX8M Evaluation Kit. All ownership, copyright and other intellectual property rights in and to the Software belong to ArWest. If these license terms are not acceptable, return any unused software and application notes.

**CONFIDENTIALITY** – These Application Notes, its contents and the Software (collectively, the “Confidential Information”) are the confidential and proprietary information of ArWest. You agree to treat ArWest' Confidential Information with a degree of care no less stringent than the degree of care you would use in safeguarding your own most valuable trade secrets. Nothing in this paragraph shall restrict you from disclosing Confidential Information to your employees as may be necessary or appropriate to operate or care for the BT4EX8M Evaluation Kit. Such employees must also keep the Confidentiality Information confidential. In the event you become legally compelled to disclose any of the Confidential Information, you shall give ArWest immediate notice so that it may seek a protective order or other appropriate remedy.

**WEBSITE; OTHER STATEMENTS** – No statement contained at the ArWest website (or any other website) or in any other advertisements or ArWest literature or made by an employee or independent contractor of ArWest modifies these Terms and Conditions (including the Software license, warranty and limitation of liability).

**SAFETY** – Improper use of the BT4EX8M OEM boards can lead to injury to persons or property and/or malfunction of the product. The BT4EX8M Evaluation Kit should only be repaired by authorized ArWest warranty service center. Users should review and heed the safety warnings in Appendix B on page 17.

**MISCELLANEOUS** – The above Terms and Conditions may be amended, modified, superseded, or canceled, at any time by ArWest. The above Terms and Conditions will be governed by, and construed in accordance with, the laws of the State of California, without reference to conflict of laws.

## Regulatory Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

“Changes or modifications not expressly approved by the manufacturer could void the user’s authority to operate the equipment”.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

## **WEEE Directive**

The following information is for EU-member states only:

The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the take-back and recycling of this product, please contact your supplier where you purchased the product or consult.



## **Technical Assistance**

If you have a problem and cannot find the information you need in the product documentation, contact your local dealer. Alternatively, request technical support using the ArWest World Wide Web site at: [www.arwestcom.com](http://www.arwestcom.com).

## **Return Material Authorization**

Initially, the customer contacts support to report a problem. Please refer to support: [support@arwestcom.com](mailto:support@arwestcom.com)

If support determines the problem cannot be resolved over e-mail/internet, it will authorize the return of the unit for repair or replacement, depending on the nature of the problem.

## **Preface**

Return Material Authorization



## Introduction

- Bluetooth Antenna:



**Figure 1-2. 4-Bluetooth Antenna**

- USB cable:



**Figure 1-3. USB cable**

- DB9 Female - DB9 Female Null-Modem Serial Cable.



**Figure 1-4. DB9 Serial Cable**

- USB AC Adapter:



**Figure 1-5. USB AC Adapter**

# CONNECTION

## 2.1. Powering the Evaluation Board

The BT4EX8M Evaluation board can be powered in two ways, using USB cable:

1. When the board is connected to PC via USB cable no additional powering required;
2. When the serial or parallel connection to PC is used, power the test board using USB cable connected to plug, as depicted on Figure 2-1:




Figure 2-1. Powering

## 2.2. Bluetooth Antenna Connection

Connect the Bluetooth antenna to the Bluetooth antenna connector, as depicted on Figure 2-1.

## 2.3. USB Connection

A standard USB cable (included in Kit) may be used to connect PC USB port with USB port on adapter.


**Table 2-1. USB Connector Specification**

Pin	Signal Name	Dir	Description
1	5V_USB	I	+5 VDC Power Input
2	USB_D-	I/O	USB data minus
3	USB_D+	I/O	USB data plus
4	GND	-	Ground
5	GND	-	Ground

## 2.4. Serial RS-232 Connection

A standard Null-Modem cable (included in Kit) with DB-9 Female connectors on both ends may be used to connect PC COM\_X port with Serial port on adapter.

Adapter's DB-9 male connector external view and pinout is shown on the Figure 2-2.



**Figure 2-2. DB-9 Male connector**

**Table 2-2. DB-9 Male Connector Specification**


Pin	Signal Name	Dir	Description
1	N/C <sup>1</sup>	-	
2	RX_IN	I	RS232 data input
3	TX_OUT	O	RS232 data output
4	N/C	O	
5	GND	-	Ground
6	N/C	-	
7	RTS_OUT	O	RS232 request to send active low
8	CTS_IN	I	RS232 clear to send active low
9	N/C	-	

1. N/C - Not connected

## 2.5. Parallel Connection

A standard parallel cable (not included in Kit) with DB-25 Female connectors on both ends may be used to connect PC LPT\_X port with LPT port on test board.

Test board's DB-25 male connector external view and pinout is shown on the Figure 2-2.



**Figure 2-3. DB-25 Male connector**

**Table 2-3. Connector Specification**

Pin	Signal Name	Dir	Description	Pin	Signal Name	Dir	Description
1	N/C <sup>1</sup>			14	N/C		
2	SPI_CSB	I	Chip select for Synchronous Serial Interface. Active low.	15	N/C		
3	N/C			16	N/C		
4	N/C			17	N/C		
5	N/C			18	GND	-	Ground
6	N/C			19	GND	-	Ground
7	N/C			20	GND	-	Ground
8	SPI_MOSI	I	Serial Peripheral Interface data input	21	GND	-	Ground
9	SPI_CLK	I	Serial Peripheral Interface clock	22	GND	-	Ground
10	SPI_MISO	O	Serial Peripheral Interface data output	23	GND	-	Ground
11	N/C			24	GND	-	Ground
12	N/C			25	GND	-	Ground
13	N/C						

1. N/C - Not connected

Please, refer to particular external device parallel port specification to select and use right Serial cable for proper connection.

## Connection

Test Pins Connection

PIO (J3)

## 2.6. Test Pins Connection

### 2.6.1. PIO (J3)

Pin	Signal Name	Dir	Description	Pin	Signal Name	Dir	Description
1	PIO0	I/O	Control output for external LNA (if fitted)	13	PIO6	I/O	Programmable input/output line or optional WLAN_Active/Ch_Data input for co-existence signaling
2	GND	-	Ground	14	GND	-	Ground
3	PIO1	I/O	Control output for external PA (if fitted)	15	PIO7	I/O	Programmable input/output line
4	GND	-	Ground	16	GND	-	Ground
5	PIO2	I/O	Programmable input/output line	17	PIO8	I/O	Programmable input/output line
6	GND	-	Ground	18	GND	-	Ground
7	PIO3	I/O	Programmable input/output line	19	PIO9	I/O	Programmable input/output line
8	GND	-	Ground	20	GND	-	Ground
9	PIO4	I/O	Programmable input/output line or optional BT_Priority/Ch_Clk output for co-existence signaling	21	PIO10	I/O	Programmable input/output line
10	GND	-	Ground	22	GND	-	Ground
11	PIO5	I/O	Programmable input/output line or optional BT_Active output for co-existence signaling	23	PIO11	I/O	Programmable input/output line
12	GND	-	Ground	24	GND	-	Ground

### 2.6.2. AIO (J6)

Pin	Signal Name	Dir	Description	Pin	Signal Name	Dir	Description
1	AIO0	I/O	Programmable input/output line	4	GND	-	Ground
2	GND	-	Ground	5	AIO2	I/O	Programmable input/output line
3	AIO1	I/O	Programmable input/output line	6	GND	-	Ground

### 2.6.3. PCM (J7)

Pin	Signal Name	Dir	Description	Pin	Signal Name	Dir	Description
1	PCM_OUT	O	Synchronous data output	5	PCM_SYNC	I/O	Synchronous data sync
2	GND	-	Ground	6	GND	-	Ground
3	PCM_CLK	I/O	Synchronous data clock	7	PCM_IN	I	Synchronous data input
4	GND	-	Ground	8	GND	-	Ground

### 2.6.4. RESET (J8)

Pin	Signal Name	Dir	Description
1	3V3	O	+3.3 VDC Power Output
2	RESET	I	Reset

### 2.6.5. 1V8 (J9)

Pin	Signal Name	Dir	Description
1	1V8	O	+1.8 VDC Power Output (for test only)
2	GND	-	Ground

## **Connection**

Test Pins Connection

1V8 (J9)

# WARRANTY TERMS

ArWest Communications Corp., Inc. (“Company”) warrants, to the end-user only, that the Narrow Band Radio Modems (“Radios”) purchased (a) conforms to the Company’s published specifications for the model purchased, and (b) is free from defects in material or workmanship. The duration of this warranty is twelve (12) months<sup>1</sup> from date of purchase and any claim for breach of warranty must be brought to the Company’s attention within such twelve (12) month period and the Receiver must be returned for action on any such claim within twelve (12) months from the date of purchase. Within a reasonable period of time after a claim, the Company will correct any failure of the Radio to conform to specifications or any defect in materials or workmanship, or replace the Radio, or, at its option, provide a full refund of the purchase price. A repaired or replaced product is warranted for 90 days from the date of return shipment to the buyer, or for the balance of the original warranty period, whichever is longer. These remedies are the buyer’s exclusive remedies for breach of warranty.

To obtain warranty service, the buyer must return the Radio, postage-paid, with proof of the date of original purchase and the buyer's return address to the Company or an authorized service center. The Company will not be responsible for any loss or damage to the product incurred while it is in transit or is being shipped for repair. It is the buyer's responsibility to arrange for insurance, if the buyer so desires.

The Company does not warrant (a) any product, components or parts not manufactured by the Company, (b) defects caused by failure to provide a suitable installation environment for the Radio, (c) damage caused by disasters such as fire, flood, wind, and lightning, (e) damage caused by unauthorized attachments or modification, (f) damage during shipment, (g) any other abuse or misuse by the buyer, (h) that the Radio will be free from any claim for infringement of any patent, trademark, copyright or other proprietary right, including trade secrets.

THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND IF APPLICABLE, IMPLIED WARRANTIES UNDER ARTICLE 35 OF THE UNITED NATIONS CONVENTION ON CONTRACTS FOR THE INTERNATIONAL SALE OF GOODS.

IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING DIRECTLY OR INDIRECTLY OUT OF THE OWNERSHIP, USE OR OPERATION OF THE RADIO REGARDLESS OF WHETHER SUCH DAMAGES ARE PREDICATED OR BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT TORT, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF SAVINGS OR REVENUE, LOSS OF USE OF THE RADIO OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF ANY SUBSTITUTE EQUIPMENT, FACILITIES OR SERVICES, THE CLAIMS

---

1. The warranty against defects in ArWest adapter, antenna, battery, charger, or cable is 90 days.

## Warranty Terms

OF THIRD PARTIES, INCLUDING CUSTOMERS AND INJURY TO PROPERTY. THIS LIMITATION DOES NOT APPLY TO CLAIMS FOR PERSONAL INJURY. SOME STATES DO NOT ALLOW LIMITS ON WARRANTIES, OR ON REMEDIES FOR BREACH IN CERTAIN TRANSACTIONS. IN SUCH STATES, THE LIMITS IN THIS PARAGRAPH AND THE PRECEDING PARAGRAPH MAY NOT APPLY.

No employee of the Company, or any other party, is authorized to make any warranty in addition to those made in this document. This warranty allocates the risks of product failure between the Company and the buyer. This allocation is recognized by both parties and is reflected in the price of the goods. The buyer acknowledges that it has read this warranty, understands it, and is bound by its terms. This limited warranty is governed by the laws of the State of California, without reference to its conflict of law provisions or the U.N. Convention on Contracts for the International Sale of Goods.

# SAFETY WARNINGS

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Clean only with a damp cloth.
- Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, or has been dropped.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, shall be placed on the apparatus.

## B.1. General Warnings

This product should never be used:

- Without the user thoroughly understanding operator's manual.
- After disabling safety systems or altering the product.
- With unauthorized accessories.
- Contrary to applicable laws, rules, and regulations.

**DANGER: THE EVALUATION KIT SHOULD NEVER BE USED IN DANGEROUS ENVIRONMENTS.**



900 Rock Avenue, San Jose, CA 95131 USA  
Tel: + 1(408) 770-1790  
Fax: + 1(408) 770-1799  
**[www.arwestcom.com](http://www.arwestcom.com)**

Copyright © ArWest Communications, 2010  
All rights reserved. No unauthorized duplication.